


Operating Instructions



Data Logger **ALMEMO® 2590-9** **VS**

V2.0
26.06.2003

Operating Controls



(1) ON/OFF switch

up ON
down OFF

(2) Meas. inputs M0 to M8

M0 ... M8 for all ALMEMO sensors
M10...M38 27 additional channels

(3) Output sockets A1, A2

A1 Interface V24 (ZA 1909-DK)
Fiber optics V24 (ZA 1909-DKL)
Centronics (ZA 1936-DK)
RS 422 (ZA 5099-NVL/NVB)
Analog output 1 (ZA 1601-RK)
A2 Network cable (ZA1999-NK/NKL)
Trigger input (ZA 1000-ET/EK)
Relay outputs (ZA 1000-EGK)
Analog output 2 (ZA 1601-RK)

(4) Control lamps

SLEEP sleep mode
CHARGE battery recharge

(5) Connector socket DC 12V

Mains adapter (ZB 2590-NA, 12V, 0.8A)
Cable, electr. isol. (ZB 2590-UK, 10-30V)

(6) LCD display

Status line

c Cont. measuring point scan
▶, II Start, stop measurement
REC Memory record
COM Output of meas. val.
>, >| Meas. start, end progr.
R01 Alarm relay status
*, * Light on, pause
■, ■ Mains/batt. oper./charge stat.

13 lines für functions

function of keys F1, F2, F3, F4

(7) Operat. dial (▲▼ turn, ▶ press)

M▲▼ meas. pt. select.
P ▶, F▲▼ function select.
P ▶, ▲▼, ▶ ... data input

(8) Control keys

PROG function selection, input
ESC function abort, menu
F1...F4 function keys (soft keys)

(9) Battery pack (back of unit)

6 R6 round cells NiMH batt. 7.2V

Operating Instructions

Data Logger

ALMEMO® 2590-9

For reference with the ALMEMO® Manual

Table of Contents

	Page
OPERATING CONTROLS	2
1 INTRODUCTION	6
1.1 Function Range	6
2 INITIAL OPERATION	11
3 POWER SUPPLY	12
3.1 Battery Operation and Supply Voltage Control	12
3.2 Mains Operation	12
3.3 External DC Voltage Supply	13
3.4 Switch On/Off, Reinitialisation	13
3.5 Data Buffering	13
4. CONNECTION OF THE TRANSDUCERS	14
4.1 Transducers	14
4.2 Measuring Inputs and Additional Channels	14
5 DISPLAY AND KEYPAD	16
5.1 Display and Menu Selection	16
5.2 Function Keys	17
5.3 Control Symbols	17
5.4 Function Selection	18
5.5 Data Entry	18
5.6 Locking of the Menus and the Keypad	19
6 MEASURING USING THE MEASUREMENT MENUS	21
6.1 Display of a Measuring Point	22
6.1.1 Selecting the Measuring Point	22
6.1.2 Peak Value Memory with Time and Date	22
6.1.3 Output of Menu Functions	23
6.2 Measuring Point Scans and Output	23
6.2.1 Manual Single Output/Storage of all Measuring Points	23
6.2.2 Cyclic Output/Storage of all Measuring Points	24

	Page
6.2.3	Print Cycle, Timer, Output Format
6.2.4	Displaying Measured Values as a Line Chart
6.2.5	Continuous Output/Storage of all Measuring Points
6.2.6	Memory Space, Memory Output, Clearing the Memory
6.3	Correction of the Measured Value and Compensation
6.3.1	Setting the Measured Value to Zero
6.3.2	Sensors adjustment, Zero Point and Slope
6.3.3	Setpoint Entry
6.3.4	Temperature Compensation
6.3.5	Atmospheric Pressure Compensation
6.4	Averaging
6.4.1	Attenuation of Meas. Values
6.4.2	Averaging Mode
6.4.3	Averaging over Manual Single Measurements
6.4.4	Averaging over Cyclic Measuring Point Scans
6.4.5	Averaging over Time
6.4.6	Measurement Time
6.4.7	Volume Flow Measurement
6.5	Display of Several Measuring Points
6.5.1	Menu Multi Channel Display
6.5.2	Menu Meas. Point List
6.6	Configuration of User Menus
6.6.1	Function Printouts
6.6.2	Configuration via Interface
7	TIMES AND CYCLES
7.1	Time and Date
7.2	Print Cycle with Storage Activation, Output Format
7.3	Measuring Cycle and Storage Activation
7.4	Conversion Rate, Continuous Measuring Point Scan
7.5	Time and Date of Start, Time and Date of End
8	DATA MEMORY
8.1	Option Smart Media Card
8.2	Data Acquisition
8.3	Numbering of Measurements
8.4	Memory Display
8.5	Memory Output
8.6	Sleep Mode

	Page
9	SENSOR PROGRAMMING
	50
9.1	Selecting the Input Channel
	50
9.2	Measuring Point Designation
	51
9.3	Averaging Mode
	51
9.4	Locking of the Sensor Programming
	51
9.5	Limit Values
	52
9.6	Scaling, Decimal Point Setting
	52
9.7	Correction Values
	53
9.8	Changing the Dimension
	53
9.9	Selecting the Measuring Range
	53
9.10	Special Functions
	56
9.10.1	Print Cycle Factor
	56
9.10.2	Minimum Sensor Supply Voltage
	56
9.10.3	Limit Value Responses, Relay Allocation
	57
9.10.4	Analog Output Start/End
	58
9.10.5	Output Function
	58
9.10.6	Reference Channel
	59
9.10.7	Multiplexer
	59
9.10.8	Element Flags
	59
10	DEVICE CONFIGURATION
	60
10.1	Device Designation
	60
10.2	Device Address and Networking
	60
10.3	Baud Rate, Data Format
	61
10.4	Language
	61
10.5	Illumination and Contrast
	61
10.6	Atmospheric Pressure
	61
10.7	Hysteresis
	61
10.8	Operating Parameter
	62
11	OUTPUT MODULES
	62
11.1	Data Cable
	62
11.2	Relay Trigger Cable , Configuration, Relay Triggering
	63
11.3	Analog Output , Scaling, Channel Selection, Programmed Output
	64
12	TROUBLESHOOTING
	65
	APPENDIX
	Electromagnetic Compatibility
	66
	Technical Data
	67
	Product Overview
	67
	Keyword Index
	68

1. INTRODUCTION

The data logger **ALMEMO®** 2590-9 is a new instrument from the unique product range of measuring devices that are all equipped with the ALMEMO® connector system, which has been patented by Ahlborn GmbH. The intelligent ALMEMO® connector provides important advantages with regard to the connection of sensors and peripherals as all parameters are stored in an EEPROM within the connector. As a result, the programming that usually has to be performed for the connection is not required. All sensors and output modules can be connected to all ALMEMO® measuring devices in the same way. The operation and programming is identical with all units. Therefore, all of the ALMEMO® measuring system items listed below are described, in detail, in a separate ALMEMO® manual that is supplied with every device:

- Detailed description of the ALMEMO® system (manual section 1)
- Overview of the device functions and measuring ranges (manual section 2)
- All sensors with basic principles, operation, technical data (man. section 3)
- The options for connecting existing sensors (manual section 4)
- All analog and digital output modules (manual section 5.1)
- The interface module RS232, fiber optics, Centronics (manual section 5.2)
- The entire ALMEMO® networking system (manual section 5.3)
- All functions and their control via the interface (manual section 6)
- A complete interface command list with all print outputs (manual section 7)

These operating instructions only cover features and controls that are specific for a certain device. As a result, many sections will often provide a note referring to the more detailed description within the manual (man. sect. x.x.x).

1.1 Function Range

The ALMEMO® 2590-9 data logger has 9 electrically isolated measuring inputs with up to 36 measuring channels for more than 65 measuring ranges, a real time clock and a 500kB memory for approximately 100000 measured values. External memory devices can be attached as an option. The device can be operated by means of the LCD graphic display, a softkey keypad and an operating dial. User menus can be configured to adapt the display for any application. Two output sockets allow for connecting any ALMEMO® output modules, for example, the analogue output, digital interface, trigger input or alarm contacts. Several devices can be networked by simply connecting them with network cables.

SENSOR PROGRAMMING

The measuring channels are automatically programmed by the ALMEMO® connectors. However, the user can easily complete or modify the programming via keyboard or via interface.

Measuring Ranges

There are corresponding measuring ranges for sensors with a non-linear characteristic such as 10 thermocouple types, Ntc and Pt100 sensors, infrared sensors, and flow sensors (rotating vanes, thermoanemometers, pitot tubes). Humidity sensors are available with function channels that also calculate humidity data such as dew point, mixture ratio, vapour pressure and enthalpy. Even complex chemical sensors can be used. The acquisition of measured data from other sensors is easily possible by using the voltage, current and resistance ranges with individual scaling in the connector. Existing sensors can be used without problems. Only the corresponding ALMEMO® connector has to be connected using its terminals. Furthermore, there are adapter connectors with an own microcontroller for digital signals and for measuring frequencies and pulses. This way, nearly all sensors can be connected to any ALMEMO® measuring instrument and are interchangeable without requiring any settings.

Function Channels

Maximum, minimum, average values and differences of certain measuring junctions can be programmed as function channels and can be processed and printed like normal measuring junctions. Furthermore, function channels for special measuring tasks are provided to determine the temperature coefficient $Q/\Delta T$ and wet bulb globe temperature.

Dimension

The 2 digit dimension can be altered for each measuring channel so that the display and the printout will always indicate the correct dimension, for example when a transmitter is connected. The conversion from °C to °F is automatically performed according to the dimension.

Name of Measured Values

For identification of the sensors a 10-digit alphanumeric name is provided. It is entered via the keypad or the interface and appears on the display, the printout or the computer display.

Correction of Measured Values

For correcting measured values a zero point and slope (gain) correction can be applied to the measured value of each measuring channel. This also allows for sensors to be interchanged that usually, at first, require an adjustment (expansion, force, pH). The zero point and the slope (gain) correction are virtually performed by the push of a button.

Scaling

The base value and the factor allow for a further scaling of the corrected measured value of each measuring channel for zero point and slope (gain). The decimal point position can be set by the exponent. By setting to zero and entering the nominal value the scaling values can be automatically calculated.

Limit Values and Alarm

Two limit values (1 max and 1 min) can be set for each meas. channel. An alarm value printout can be performed if a limit value is exceeded and, by means of relay output modules, alarm contacts are provided that can be individually allocated to limit values. As a standard, the hysteresis is set to 10 digits; however, it can also be adjusted between 0 and 99 digits. Furthermore, limit value exceeding can also be used to start or stop a data logging.

Sensor Locking

All sensor data stored in the EEPROM of the connector can be protected against undesired access by means of a graded locking function.

MEASUREMENT

A total of up to 36 meas. channels are available for 9 transducers, i.e. it is also possible to evaluate double sensors, individually scaled sensors, or sensors with function channels. The meas. channels can be successively selected forwards or backwards via keypad or operating dial. As a standard, the meas. values of all active meas. channels are continuously acquired at a rate of 10 meas.points/sec and indicated on the display or, if available, provided on the analog output. In case of a large number of meas. points the meas. point scan can be limited to one selectable meas. point to increase the response speed.

Measured Values

The measured values of 1 to 20 measuring points can be indicated on the display in 7 different menus (that can also be configured) in three font sizes, as bar graph or as line chart. They are automatically acquired with auto zero and self calibration and can also be arbitrarily corrected and scaled as required. A sensor breakage condition is, with most sensors, automatically detected.

Analog Output and Scaling

By means of analog start and analog end any measuring point can be scaled so that the resulting measuring range covers the full range of the bar graph or line chart or of an analog output (2V, 10V or 20mA). The measured value of any measuring point as well as a programmed value can be output to the analog output

Measuring Functions

Special measuring functions are required for some sensors to achieve an optimal data acquisition. The cold junction compensation is available for thermocouples, a temperature compensation for dynamic pressure and pH and conductivity probes, and an atmospheric air pressure compensation for humidity sensors, dynamic pressure sensors and O₂ sensors. With infrared sensors the parameters zero point and slope correction are used for background temperature and emissivity factor.

Max and Min Value

Each measurement involves an acquisition and storage of the Max value and the Min value including the time and date. The values can be displayed, printed or cleared.

Average Value of a Channel

A manual averaging over a particular period or over single measurements is available for the selected channel.

PROCESS FLOW PROGRAMMING

A cyclic measuring point scan with a time-based process flow control is required to register the measuring data of all connected sensors. For this purpose, the real time clock, the print cycle and the measuring cycle are available and, if fast processing is required, the conversion rate is available. The measurement can be started and stopped by using the keyboard, the interface, an external trigger signal, the real time clock or an exceeding of limit values.

Time and Date

The real time clock with date function or the pure measuring time are used for an accurate recording of any measurement. Start and end time/date can be programmed in order to start or stop a measurement.

Print Cycle

The print cycle is programmable between 1s and 59h/59min/59s and provides a cyclic output of measured values to the interfaces or memories and also provides a cyclic averaging.

Print Cycle Factor

If necessary, the print cycle factor allows for limiting the data output of particular channels so that an excessive data flow can be limited, especially during data storage.

Measuring Cycle

The measuring cycle, also programmable between 1s and 59h/59min/59s, is for a cyclic scanning with limit value monitoring, alarm message, output of alarm values, averaging and, possibly, data storage.

Average Value over Measuring Point Scans

The measured values resulting from scanning measuring junctions can be averaged as desired either over the total measuring time or over the print cycle time. Function channels are available for a cyclic output and storage of these average values.

Conversion Rate

With the ALMEMO® 2590-9 all measuring points can be continuously scanned with the conversion rate (2.5;10 or 50 M/s). To realize a high recording speed it is possible to store all measured values in the memory and/or to perform an output via the interface.

Data Memory

During the measuring or print cycle, all measured values or alarm values can be manually or automatically stored in a buffered RAM. The memory capacity is, as standard, 500kB, which allows up to 100000 measured values. The memory organisation can be configured as linear or ring memory. As an option, a Smart Media Memory Card up to 32 MB can be used as storage device. The programming is

saved with each change of the configuration. The output can be carried out via the display or the interface. It is possible to specify a selection according to a time interval, number or alarm value.

Numbering of Measurements

By entering a number, single scans or entire series of measurements can be identified and selectively read out from the memory.

Control Outputs

Via keyboard and interface allows to individually trigger up to 4 output relays and one analog output.

Operation

All measuring and function values can be displayed in different menus on the dot matrix LCD display. 3 user menus can be individually configured from nearly 50 functions for your specific applications. Using texts, lines and blank lines allows to format the printout in an application-specific style. 6 keys (four of them are soft keys) and an operating dial can be used to operate the device. This also allows you to fully program the sensors, the device and the process control. A graded locking function including a password lock is available to limit the access to the menu and the operating keys, as required.

Output

All data logs, menu functions and stored measured values and programmed parameters can be provided as output to any peripheral equipment. Various interface cables can be used to provide a RS232, RS422, Centronics or Ethernet interface. The output of measuring data can be selected in list format, columns or spreadsheet format. Files in spreadsheet format can be processed by each spreadsheet software. The print header can be programmed specifically to the company or application.

Networking

All ALMEMO® devices can be addressed and can be easily networked by simply linking them using network cables, or RS422 network distributors for longer distances.

Software

The AMR-Control software, which allows for the entire programming of the sensors, the configuration of the measuring instrument and the read-out of the data memory is supplied with each ALMEMO® manual. The integrated terminal also allows for online measurements. The WINDOWS® software packages, WIN-Control and DATA-Control, are available for data acquisition of networked devices, graphical presentation and complex data processing.

2. INITIAL OPERATION

Sensor connection Connect transducers to the sockets **M0** to **M8** (2), s. 4.

Power supply Internal battery or mains adapter, see 3.1, 3.2

Switch-on Move the left slide switch (1) upwards, see 3.4

Displaying meas. data Keys

Call up the main menu 'ALMEMO 2590-9' if required

Select menu **StandardDisplay**

Call up menu **StandardDisplay**

Select meas. point. Meas. value, max/min value will be displayed. **F1** or **<M▲>**

Clear max/min values: Select function **Max/MinVal** **PROG, F4<F▼>...**

- Clear single value **F1** or **<CLR>**

- Clear max/min and average values of all channels, s. 6.1.2 **F2** or **<CLRA>**

ESC

F3 or **<F▲>...**


PROG

F1 or **<M▲>**

PROG, F4<F▼>...

F1 or **<CLR>**

F2 or **<CLRA>**



For output of measuring data or memory via interface:

- Connect peripheral device, via interface cable, to socket A1, see man. 5.2
- Set 9600bd, 8 data bits, 1 stop bit, no parity at peripheral device
- Set output format ' ', columns 'n' or table 't', as required, see 7.2

Output and storage of measuring data

Single output/storage of all measuring points, see 6.2.1

Enter print cycle for cyclic measurement, see 7.2

Enter the current time and date, as required, see 7.1

Start/stop the cyclic measurement, see 6.2.2

Output of memory data to printer or computer

Select the function **MemoryFree**

Memory data output, s. 6.2.6

Clear memory

Keys

F4 or **<MANU>**

F3 / **<START/STOP>**

PROG, F4 / **<F▼>...**

F2 or **<PRINT>**

PROG, F1 / **<CMEM>**


3. POWER SUPPLY

The following options are available for the power supply of the instrument:

- NiCd batt. pack 7.2V built-in or supplement. batt. pack ZB 2590-AP
- Mains supply unit or battery charger 12V/800mA ZB 2590-NA
- Electr. isol. power supply cable (10..30V DC, 1A) ZB 2590-UK

Our product line includes corresponding accessories.

3.1 Battery Operation and Supply Voltage Control

A battery pack with 6 NiMH cells (7.2V/1600mAh) is used as the standard power supply of the device. At a current consumption of approx 31mA, they last for an operating time of 52 hours. If the illumination is constantly switched on, this operating period is reduced to approx. 28 hours. To extend the operating time for long term recording it is possible to operate the device in Sleep Mode (s. 8.6) or to just switch the display off. When a remaining battery capacity of approx. 10% is reached, the symbol  will be indicated in the status line of the display. Generally, the batteries should then be recharged using the supplied mains adapter ZB 2590-NA, otherwise the batteries can suffer damage from deep discharge. If the battery is completely discharged, the instrument will switch off. However, meas. data and time will be maintained in the battery buffered memory (see 3.5). A supplementary battery pack ZB 2590-AP can be used in exchange to immediately continue the device operation.

Tips regarding the correct handling of rechargeable batteries:

- In most cases, the batteries supplied are not charged when delivered!
- If NiMH cells are only partly discharged, the full capacity cannot be reached by a normal recharging.
- Therefore, use the device until the batteries are nearly totally discharged.
- Completely recharge the batteries afterwards.
- As a result, the life of the batteries is significantly increased.
- Completely recharged batteries will slowly discharge during storage, therefore, they should be charged at least once per month.
- The current battery voltage can be checked in the device configuration, allowing an estimation of the remaining operating time.

3.2 Mains Operation

For external supply of the instrument and for recharging the batteries the supplied mains adapter ZB 2590-NA (12V/800mA) must be connected to the socket DC (5). After plugging in, the small lamp 'CHARGE' is illuminated and indicates that the batteries are being recharged. The batteries are recharged after 4 hours, at maximum, and the small lamp switches off, i.e. the charger circuitry has switched to trickle charge. The mains adapter can, offering a buffer operation, stay continuously connected to the measuring instrument.

3.3 External DC Voltage Supply

It is also possible to connect another DC voltage, 12V $\pm 5\%$ (800mA), to the socket **DC** (5). The connection is performed by using a low voltage connector (NES1 according to DIN 42323), center pin to minus. However, the electrically isolated supply cable ZB 2590-UK must be used if an electrical isolation between power supply and transducers is required or if a larger input voltage range 10...30V is required. It allows to operate the measuring instrument with 12V or 24V on-board supply systems.

3.4 Switch On/Off, Reinitialisation

The slide switch (1) on the left side must be used to switch the device on or off.

- up: **ON**
- down: **OFF**

After switch-off the real time clock continues its operation and all stored data remains available by a buffer battery (see 3.5). If the device was operating in a measurement menu before switch-off it will return to the corresponding menu after switch-on, otherwise the main menu will be displayed.

If the device shows an irregular behaviour due to interference influences (e.g. electrostatic charging or discharged buffering battery) or if incorrect programming must be avoided, the device can be reinitialised. The **reset** can be achieved if the key F1 is pressed during switch-on. All internal data such as maximum and minimum values and the data memory will be cleared and the user menus will be set to the delivery defaults. Furthermore, cycles, time, date and device address are set to zero and the conversion rate and atmospheric pressure will be set to the standard values. However, the device configuration and the sensor programming within the ALMEMO[®] connectors will not be affected by the reset.

3.5 Data Buffering

The sensor programming is stored in the EEPROM of the sensor connector, the calibration of the instrument is fail-safe stored in the EEPROM of the instrument. The instrument, measuring data, as well as the time and date are buffered by the lithium battery so that storage of the data is also guaranteed when the device is switched off or when the batteries are discharged.

4. CONNECTION OF THE TRANSDUCERS


Any ALMEMO® sensors can be connected to the ALMEMO® input sockets M0 to M8 of the measuring instrument (2). For connecting existing sensors it is only necessary to connect a corresponding ALMEMO® connector.

4.1 Transducers

A detailed description of the comprehensive ALMEMO® sensor range (see manual section 3) and the connection of existing sensors (see manual section 4) to the ALMEMO® instruments are provided in the ALMEMO® manual. All standard sensors with ALMEMO® connector usually have the measuring range and dimension already programmed and can be immediately connected to any input socket. A mechanical coding ensures that sensor and output modules can only be connected to the correct sockets. Furthermore, each ALMEMO® connector has two locking levers that snap in when the insertion into the socket is established and that prevent a disconnection caused by pulling the cable. Both levers must be pressed on the sides for disconnecting the connector.

4.2 Measuring Inputs and Additional Channels

The measuring instrument ALMEMO® 2590-9 has 9 input sockets (2) that the measuring channels M0 to M8 are initially allocated to. However, ALMEMO® sensors can, if required, provide up to 4 channels so that 36 channels are available with 9 input sockets. The additional channels can be especially used with humidity sensors with 4 measuring variables (temperature/humidity/dew point/mixture ratio) or used for function channels. If required, the sensor can also be programmed with several ranges or scaling or, depending on the pin assignment, 2 or 3 sensors can be combined in one connector (e.g. rH/Ntc, mV/V, mA/V etc.). The additional measuring channels of a connector are increased in steps of 10 (e.g. the first sensor has the channels M0, M10, M20, M30, the second sensor has the channels M1, M11, M21, M31 etc.).






The 9 analog inputs are electrically isolated by using photovoltaic relays and a potential difference of 50V DC or 60V AC, at maximum, is permissible between them. However, sensors combined within one connector and sensors with an own power supply are electrically connected to each other and must, therefore, be operated in isolation. The voltage applied to the measuring inputs must not exceed $\pm 12V$ (between B,C,D and A or - respectively).

The cold junction compensation for thermocouple measurement is integrated in socket M4 of the device.

5. DISPLAY AND KEYPAD

5.1 Display and Menu Selection


The display (6) of the measuring instrument ALMEMO 2590-9 consists of a dot matrix LCD display with 128x128 dots, or 16 lines with 21 characters each, respectively. 11 standard menus and 3 user-definable 'user menus' U1, U2, U3 are available and can be selected at the main menu for the acquisition of measuring data in connection with the required functions and for the programming of the process control, the sensors and the device parameters.



If necessary, call up the main menu using the key
 Switch-on of the display illumination (see 10.5)
 Selection among standard or user menus (S1..S3/U1..U3)
 Selection of the menus
 Calling up the selected menu

ESC
 F1 <*ON>
 F2 <S/U>
 F3 <F▲>, F4 <F▼>
 PROG

Alternatively, the operating dial (7) on the right side of the device can be used by turning it upwards or downwards and pressing the dial at the side to confirm.



Returning to the main menu is only possible by using the key

ESC



A graded locking function incl. a password lock is available to limit the access to the menu and the operating keys as required (s. 5.6). The setting is indicated in the 1st line of the main menu.




The device designation in the header line (see 10.1) can be as easily programmed as the menu titles of the user menus (see 6.6).

5.2 Function Keys

The function of the keys F1 to F4 can be different in the various menus. It is indicated by abbreviations in the bottom line of the display (soft keys). In the manual the soft key abbreviations are set in angle brackets, e.g. <START>.

Next to the meas. value, control symbols for the meas.value are displayed (s. below).

The following keys are available in the standard display:



Selection of measuring points
 Output of menu functions via the interface
 Starting a cyclic measurement
 Stopping a cyclic measurement
 Single manual output/storage of all measured values
 Returning back to the main menu

F1 <M▲>
 F2 <PRINT>
 F3 <START>
 F3 <STOP>
 F4 <MANU>
 ESC

5.3 Control Symbols

Symbols for monitoring process control and battery in the status line:


Continuous measuring point scan:	C
Measurement stopped or started:	or ▶
Measuring point scan started including storing:	REC
Measuring point scan started incl. output via interface:	COM
Start/end time of measurement is programmed:	> or >
Relay status (external output module) off or on:	R-- or R01
Display illumination switched on:	*
Batt. charge state: 100% charged, discharged (connect charger):	[Full Battery Icon], [Empty Battery Icon] flashes
Charger connected:	[Charger Icon]

Symbols for checking the measured value (see above)

No sensor, measuring point deactivated:	'-----'
Measured value altered by sensor correction or scaling:	↗
Averaging in progress:	M
Output function altered (see 9.10.5):	D, H, L, M, A
Exceeding of limit value Max or Min:	▲ or ▼ flashes
Exceeding of measuring range: display of max. value	O flashes
Undershooting of meas. range: display of min. value	U flashes
Sensor breakage sensor voltage Lo : display '-.-.-'	B flashes L flashes
Supply voltage too low for measurement:	display switched off

5.4 Function Selection

Each menu consists of a number of functions that, possibly, have to be used or programmed during operation.



Selection of the functions. First changeable parameter is highlighted as inverse coloured font on a black bar.

Switching to the next function

Depending on the function, the keys F1 or F2 provide the corresponding functions, e.g. Clear Function

Set meas. value to zero, calibrate meas. value

Memory data output

Clear memory

PROG

Temperature

F4 <F▼> or F3 <F▲>

F1 <CLR>

F1 <ZERO>, F2 <ADJ>

F2 <PRINT>

PROG, F1 <CMEM>

It is also possible to **select the function** by using the **operating dial** - first press (P ►), then turn (▼▲) to select (see 5.5).

5.5 Data Entry

If a programmable parameter is selected (see 5.4) you can enter or clear the value.

Starting from a **measurement menu**, the device firstly switches to the corresponding programming menu where the parameter can be programmed.

For example:

If the print timer is selected in the standard menu, PrintTimer: **00:00:00** S
for entering the print cycle press:

The menu '* Times-Cycles *' indicates

PROG

PrintCycle: **00:00:00**

Programming using the keys

For programming, press the key

Then you are in the **input mode**,

the cursor flashes below the first cursor position

PROG

PrintCycle: **00:00:00**

The **function keys** indicate, e.g. the symbols:

Increasing the selected number with

CLR ▲ ▼

Decreasing the selected number

<▲>...

Changing the sign of numerical values

<▼>...

Clearing the programmed values

<+/->

<CLR>

Selecting the next position

PROG ▶

the cursor flashes below the second digit

PrintCycle: 00:00:00

Switching back to the previous digit

press and hold PROG ▶

Each digit is programmed analogously to the first one

<▲>..., PROG ▶

Quitting the data entry

After setting the last digit confirm with

PROG ▶


Cancelling the programming process

ESC

The input of letters, measuring ranges etc. can be carried out accordingly.

Programming using the operating dial

As an alternative to the keys a 'mouse-like' operating dial (7) is available for data entry. This method is significantly faster, particularly regarding the input of letters and measuring ranges.



First press the dial (corresponds to pressing the key PROG), then select the correct value of the digit by turning (▲▼) the dial.

To select the next digit, press the dial again, and repeat as above.

5.6 Locking of the Menus and the Keypad


The data logger ALMEMO® 2590-9 allows an extensive programming of the sensors, the measuring instrument and even of the presentation of functions within the measurement menus. However, for many measuring tasks it is very important that constraints cannot be inadvertently changed. On the other hand, the application must provide corresponding operating options. Therefore, extensive configuration options for locking are available to protect the measurement environment:

- Graded locking of the menu access
- Graded locking of the key functions
- Graded locking of the sensor programming, see 9.4

Furthermore, the configuration can be password protected.

Locking of the menu access

The menus are configured in a hierarchical form and their locking level is indicated at the first digit. The first line provides the function 'Locked: MxTx' for locking of menus and keys. If the 'M' is followed by a number from 1 to 9, the menus starting from the bottom line up to this level are locked and cannot be selected, e.g. in case of 'M1' the menus 'Device Configuration' and 'Output Modules' are locked, while 'M9' indicates that all menus, except the 'Standard Display', are locked.



Locking of the operating keys

Depending on the menu the keys provide different functions. The following functions can be locked using the corresponding locking level 'T'.

T Locked Functions

- 9 Selection of measuring points
- 8 Data output
- 7 Manual output, storage
- 6 Start/stop measurement
- 5 Function selection
- 4 Clear measuring data
- 3 Clear memory
- 2 Switch on/off of parameters
- 1 Data input, menu programming

Keys

M▲
 PRINT, DISP
 MANU
 START/STOP
 PROG, F▲, F▼
 CLR, CLRA
 CMEM
 OFF/ON
 PROG, ▲, ▼, PROG press and hold

Key operation:

Locking function:

Function Locked:

Selecting the function 'Locking':

Selecting the parameter 'Menu Locking':

Selecting the parameter 'Key Locking':

Selecting the password:

Programming:

Locking: M0T0 ----

Locked: M1T1 ****

<F▲>

PROG

PROG, <F▲>

PROG, <F▲>, <F▲>

PROG, <▲>..., PROG (see 5.4)

To also protect the locking configuration it is possible to enter a four-digit password (see 5.3), for control purposes the display will only indicate '****'. The configuration will only be accessible if the same password is entered again. However, in case of a reinitialisation the whole locking will also be cleared (see 3.4).

6. MEASURING USING THE MEAS. MENUS

The ALMEMO® 2590-9 provides the following options for the data acquisition:

Output to the display:

- Exclusive measurement of the selected measuring point, see manual 6.4
- Output of measuring data to the analog output, see manual 5.1.1
- Continuous meas. point scan of all measuring points, see 7.4 man. 6.5.1.3

Output to the interface or to the memory:


- Single manual output of the selected measuring point, see manual 6.4.2
- Single manual output/storage of all measuring points, see 6.2.1
- Cyclic output/storage of all measuring points, see 6.2.2
- Continuous output/storage of all measuring points, see 6.2.5

Display options for measured values


The measurement menus are different with regard to the number of available meas. points, the height of the digits and the additional measuring functions:

StandardDisplay	1 meas. point	13mm digit height
S1 DataLogger	1 meas. point	8mm digit height
S2 LineChart	1 meas. point	line chart
S3 MultiChannDispl	max. 4 meas.points	8mm digit height
U3 4 BarChart	max. 4 meas.points	4mm digits, analog bars
MeasValList	max. 20 meas.points	4mm digit height

StandardDisplay:



DataLogger:



A few symbols (see 5.3) identify the status of the measured value.

The standard menus for meas. values are configured with specific functions to cover the most frequent tasks. The menu 'Line Chart' can be found in section 6.2.4, 'Multi Channel Display' in 6.5.1. Furthermore, for your specific applications you can self-configure individual menus including the preferred display of meas. data and the functions you require (s. 6.6).

6.1 Display of a Measuring Point

Different from previous instruments, the continuous measuring point scan (e.g. after a reinitialisation, see 3.4) is the standard default setting of the ALMEMO 2590-9, i.e. all meas. points are continuously acquired and the meas. values can be retrieved at any time, even if they are related to other channels (e.g. with function channels, temperature or atmospheric pressure compensation).

6.1.1 Selecting the Measuring Point

The key <M▲> allows for successively selecting all active meas. points including the display of the current meas. value. If the key <M▲> is pressed and held (approx. 1s) the previous channel is again indicated. By selecting the meas. channel the input channel is, at the same time, also selected (see 9.1).

Increasing the meas. channel using the key: <M▲>

Decreasing the meas. channel using the key: <M▲> press and hold


The measuring points, as well, can very easily be increased or decreased by turning the **operating dial**.



6.1.2 Peak Value Memory with Time and Date

The highest and lowest value, including the time and date, will each time be determined and stored from the acquired measured values of each measuring point. The functions listed below are available to display these values.

The software AMR-Control can be used to easily load or configure the menu 'Monitoring' with Max/Min times (illustrated on the right) as a user menu (see 6.6).



Function max value:

MaxVal: 245.7°C

Function min value:

MinVal: 224.1°C

Function time and date of max value:

MaxTime: 12:34 01.02.

Function time and date of min value:

MinTime: 12:56 01.02.

To clear, select function (see 5.4):

MaxVal: 245.7°C

Clear single value:

<CLR>

Clear max, min and average values of all channels:

<CLRA>

If the cleared channel is also the selected measuring channel, the current measured value will be immediately displayed after the clearing process. Furthermore, the peak values are cleared at each start of a measurement, if the device has been correspondingly configured (standard setting, see 10.8).

6.1.3 Output of Menu Functions

Each data menu, together with all displayed functions, can be output via interface to a printer or computer (connection of peripheral devices, see manual 5.2). If you have selected the standard display, pressing the key <PRINT> leads to a printout of the following listing:

Print data menu:	<PRINT>
Meas. point, meas. value, designation:	01: +0023.5 °C Temperature
	MAXVAL: 01: +0020.0 °C
	MINVAL: 01: -0010.0 °C
	PRINTTIMER: 00:01:23
Total memory capacity, free mem. in kB	MEMORY: S0512.1 F0324.4 A

The listing of the individual functions is given in section 6.6.1.

6.2 Measuring Point Scans and Output

Measuring point scans allow measured values of all measuring points to be acquired, stored (if necessary) and recorded through a printer or computer (see manual 6.5). If continuous measuring point scan has been selected (the letter 'C' will be indicated at the first digit of the status line), the available measured values, on command, will only be stored or output.

6.2.1 Single Output/Storage of all Measuring Points

Single manual measuring point scans for acquiring the momentary measured values of all active measuring points can be triggered by the key <MANU> (see manual 6.5.1.1). The time will be started if it had been set to zero. If the true time of day has to be indicated, it must first be set (see 7.1). The output format can be set in the function 'PRINT CYCLE' (see 7.2, list of printouts in manual section 6.6.1).

Single manual measuring point scan: <MANU>

The following symbols will, **for a short period**, be indicated in the **status line**:

The start arrow will light up and then go off again	'▶'
Lightening up in case of a data output via interface	'COM'
Indicated when meas. values are being stored (see 8.2),	'REC'

With each press of the key the measured values are equally processed with the corresponding measuring time.

6.2.2 Cyclic Output/Storage of all Measuring Points

The print cycle (see 7.2) must be programmed for cyclic outputs of measured values (see man. 6.5.1.2) and recording. The measurement can be started using the key <START> and stopped using the key <STOP>. At each start of a measurement the max, min and average values of all meas.points are cleared, if the device has been correspondingly configured (standard setting, see 10.8).

Starting a cyclic meas. point scan:

<START>

For control purposes the following symbols will **continuously**, i.e. for the whole meas.period, be indicated in the **status line**:

The start arrow lights up

▶

Lightening up in case of a data output via interface

COM

Indicated when measured values are being stored (see 8.2):

REC

Stopping a cyclic meas. point scan:

<STOP> II

6.2.3 Print Cycle, Timer, Output Format

The function 'Print Timer' in the standard menu indicates the print cycle, as log as a measurement has not been started. After starting a measurement the timer counts down to the next cycle. If the function has been selected (see 5.4) the print cycle can be programmed (see 5.5) or the key <FORM> can be used as the quickest way to set the required output format (see 7.2).

Function 'Print Timer', 'Format List', 'Memory On': PrintTimer: 00:02:00 S

Change format: <FORM>


Format columns side by side 'n': PrintTimer: 00:02:00nS

Change format: <FORM>

Format table 't': PrintTimer: 00:02:00tS

6.2.4 Displaying Measured Values as a Line Chart

When using the menu 'Line Chart' the meas. value of the selected channel is indicated as a line chart with 100x200 dots as soon as a measurement is started. The curve continuously moves from the right to the left, the time resolution is determined by the **print cycle**, each scan involves one point (dot). Therefore, time data for the whole t axis is given as (days) hours:minutes in the bottom right corner. In the upper right corner the time of day is indicated. In this mode, the curve is also updated during an active measurement, if the user leaves the menu (in this case, do not change themeas.point!). Limit values, if activated, are entered as dotted lines. In addition, another fast display mode is available



with indicating and overwriting all measured values at the **conversion rate** from left to right.

The functions '**Analog Start**' and '**Analog End**' of the menu '**Special Functions**' can be used to set the display range of the y axis (see 9.10.4). They can be directly called up using the key '**SCALE**'.

Displaying a measured value as line chart:

Enter the print cycle in the menu '**Cycles-Times**'. PrintCycle: 00:00:05
Time axis 120 x 5s = 10min: 00:10

Scaling of the y axis in the menu '**Line Chart**':

<SCALE>

In the menu '**Special Functions**' set the analog start and analog end of the measuring channel.

Analog-Start: 20.0%H

Returning to the menu '**Liniengrafik**':

Analog-End: 80.0%H

ESC, ESC

In menu '**Line Chart**' select the meas. channel:

<M▲>

Starting the measurement:

<START>

▶

Stopping the measurement:

<STOP>

||

Changing to **fast display** using the key:

<TIME>

Check the conv. rate in the menu '**Cycles-Times**'. ConvRate: 10 Cont: -

Time axis 120 x 0.1s= 012s:

012s



Channel switching is blocked during the measurement!

At each start and at each channel switching the line chart will be cleared!

6.2.5 Continuous Output/Storage of all Measuring Points

The highest recording speed can be achieved using a continuous measuring point scan (see manual 6.5.1.3), by activating the switches '**Memory ON**' or '**Output ON**' in the function '**Conversion Rate**' (see 7.4) of the menu '**Times-Cycles**', logging all measured values that have been acquired at the conversion rate.

6.2.6 Memory Space, Memory Output, Clearing the Memory

The function '**MemoryFree**' allows, during recording of measuring data, to continuously monitor the available memory space given in kilobytes. By selecting this function, two soft keys are available for a direct output and clearing of the memory. The output format corresponds to the setting in the print cycle (see 6.2.3 and 7.2).

Function '**MemoryFree**', e.g.:

MemoryFree: 0211.0kB

Memory data output:

<PRINT>

Clear memory:

PROG, <CMEM>

6.3 Correction of the Meas. Value and Compensation

To achieve maximum accuracy of measurements it is possible to correct all sensors with regard to zero point and slope (gain) in the 'Standard Menu', by the push of a button. Additional correction functions are provided in the 'User Menu U1' (selection see 5.1) 'Meas. Correction'. By entering a setpoint the correction value will be automatically calculated and stored in the sensor connector. A corresponding compensation is provided for sensors, which are affected by the ambient temperature or the atmospheric pressure.

C ▶ REC COM >> R01 *

Meas. Correction
10: 24.5ms
 L840 Pitot Tube A ↗

Locking:	3
Setpoint:	25.0ms
Zero Point:	0.7ms
Factor:	0.6891
TempComp:	245.7°C
AtmPress:	1027mb

▲ PRINT START MANU

6.3.1 Setting the Meas.Val. to Zero

The user can zero the measured value at certain locations or at certain times in order to check the deviation from this reference value. After selecting the function 'Meas. Value' (see 5.4) the key <ZERO> can be used to store the displayed measured value as base value and, as a result, to set it to zero.

Function 'Meas. Value':

00: 23.4°C

Function 'Set Meas. Value To Zero':

<ZERO>

Meas.Val.:

00: 00.0°C ↗

Base value:

BaseValue: 23.4°C



Please note that this function is only available if the locking code is set below 5 (see 9.4).

As long as the deviation from the base value is indicated (instead of the actual measured value) the symbol ↗ appears in the display.

The base value must be cleared in order to re-obtain the actual measured value (see 9.6).

6.3.2 Sensors adjustment, Zero Point and Slope

Many sensors must be adjusted at least once or at regular intervals to compensate for instabilities. For this purpose, a specific **zero point adjustment** is available, in addition to the 'Set Meas. Value to Zero' mentioned above, as some sensors require an additional scaling (e.g. pH probes). In this function the zero point error is not stored as base value but as zero point correction (see 9.7). In this case, the locking mode must be set below 4 (see 9.4).

Function 'Zero Point Adjustment' using the key:: <ADJ>

Meas.Val: 00: **00.0**°C ↗
Zero Point: ZeroPoint: 23.4°C



If a base value has been programmed, the measured value indicated after adjustment is not zero but the negative base value.
In the case of dynamic pressure probes the zero-point error is written temporarily (i.e. until you switch off) to the calibration offset - even if the channel is locked.

In the case of **the following sensors**, if the calibration value is applied, the **same key** automatically makes a **gain adjustment** :

pH probe ZA 9610-AKYx : 4.00 pH or 10.00 pH
Conductivity : FY A641-LF : 2.77 mS/cm,
FY A641-LF2 : 147 uS/cm
FY A641-LF3: 111.8 mS/cm,
O₂ saturation : FY A640-O2: 101 %

Gain adjustment by means of key : <ADJ>

Measured value : 00: **10.00** pH ↗
Gain : Gain : 0.1689

In the case of pH probes, by pressing the <ZERO> key, you can restore the standard values, base value 7.00 and gain -0.1689.

6.3.3 Setpoint Entry

For the correction of sensor errors the zero point adjustment has already been introduced in section 6.3.1. For a two-point adjustment it is further necessary to correct the slope (gain) by performing a comparison with a second measuring point. With the function 'Setpoint Entry' the correction factor is automatically determined and stored as factor in the sensor connector.

1. Set sensor to the '**zero state**'
(ice water, unpressurized etc.),
Set the meas. value to zero by using the keys (s. 6.3.1). <ZERO> or <ADJ>

2. Put sensor to a defined **setpoint**
(boiling water, known weight etc.),
Enter the setpoint in function 'Setpoint': SetPoint: **100.0**°C

3. Calibrate the measured value in function 'Setpoint': <ADJ>

Afterwards, the measured value, as well, should indicate the set point.



In this case, as well, the locking level must be set below 5 to allow a programming of the factor (see 9.4).

6.3.4 Temperature Compensation

Sensors with measured values that are strongly depending on the temperature of the measuring medium are, in most cases, equipped with a specific temperature sensor and the instrument will automatically perform a temperature compensation (see sensor list, manual 3. 'TC'). However, dynamic pressure probes and pH probes are also available without a temperature sensor. If the temperature of the medium deviates from 25°C the following measuring errors must be considered:

e.g. error per 10 °C:	Compensation range:	Sensor:
Dyn. press: approx. 1.6%	-50 to 700 °C	NiCr-Ni
pH probe: approx. 3.3%	0 to 100 °C	Ntc or Pt100

The temperature compensation can either be performed automatically using the reference channel and external temperature sensors or manually by using the function 'Temp Comp', e.g. in the 'Measurement correction' menu, and entering the temperature:

Entering the compensation temperature in the function: TempComp: 31.2



If a temperature sensor is available and continuously measured, the temperature will be continuously indicated. This allows to display both measured values for any double sensors.

6.3.5 Atmospheric Pressure Compensation

Some measuring variables depend on the environmental atmospheric pressure (see 9.9 measuring range list 'w. PC'). As a result, higher deviations from the normal pressure of 1013mbar can cause corresponding measuring errors:

e.g. error per 100 mbar:	Compensation range:
Rel. humidity psychrometer	approx. 2% 500 to 1500 mbar
Mixture ratio, cap.	approx. 10% vapour pressure VP to 8 bar
Dynamic pressure	approx. 5% 800 to 1250 mbar (error < 2%)
O ₂ saturation	approx. 10% 500 to 1500 mbar

Therefore, the atmospheric pressure should be considered (approx. -11mb/100m over mean sea level, MSL) especially during use in a corresponding height above sea level. It can either be programmed or measured with a reference sensor (see manual 6.7.2).

The function 'Atmospheric Pressure' can be integrated into any user menu or be set in the standard menu 'Device Configuration':

Entering the atm. pressure in function 'Atm. Press.': AtmPress: 1013mb

With each reset the atmospheric pressure is set to 1013mb. It can be set to the current value by the usual data entry (see 5.5). If it is measured, the measured value will be displayed.



Please note that the last measured value will be retained when a reference sensor is being disconnected.

6.4 Averaging

The **average value** of the measured value is required for various applications:

e.g. Smoothing of a largely varying measured value (wind, pressure etc.).

The average flow velocity in a ventilating channel.

Hourly or daily average values of weather data (temp., wind etc.).


As above, of consumption values (current, water, gas etc.).

The average value \bar{M} of a measured value results when a number of measured values M_i are added together and then divided by the number N of the measured values:

$$\text{Average value } \bar{M} = (\sum M_i) / N$$

All averaging functions can be found in the 'User Menu' U2 (see 5.1) 'Average Value':

For the calculation of the volume flow from the average velocity and the cross section of a flow conduit the menu 'Flow' can be used and easily loaded with the software AMR-Control (V3.00 and higher) or can be manually generated (see 6.6).



6.4.1 Attenuation of Meas. Values through Moving Averaging

The first possibility of averaging exclusively affects the measured value of the displayed channel and serves, in case of unstable measured values, e.g. when measuring turbulent flows, to attenuate or smooth the meas. values by a moving averaging. Using the function 'Attenuation' the **level of attenuation** can be adjusted over the averaged values within the range from 0 to 99 (see 5.5). The smoothed measured value is also valid for all following evaluation functions. Therefore, the attenuation can also be used in a combination with the averaging over individual measured values (see 6.4.3), e.g. for net measurements.



Smoothing of meas.values using the function 'Attenuation': Attenuation: 20

The continuous measuring point scan should be switched off as, otherwise, for many measuring points the conversion rate will largely drop:

ConvRate: 10/s -


6.4.2 Averaging Mode

A detailed description of averaging over measuring point scans is given in the manual section 6.7.4. The type of averaging is determined through the function 'Averaging Mode'. If a sensor with an ALMEMO® connector is connected the following modes can be set (see 5.5):

Function no averaging:	Averag.Mode: -----
Averaging over all measuring point scans:	CONT M
Averaging over all scans of a print cycle:	CYCL
Average value of all measurements from start to stop:	STSTP
Lightening up for control purposes if averaging is in progress:	M

6.4.3 Averaging over Manual Single Measurements

Single manual meas. point scans Ex are performed for an averaging of isolated measurements at certain points or times (e.g. net measurements according to VDI/VDE 2640, see manual 3.5.5). At all measuring points where measured values must be averaged the averaging must be switched on by using the averaging mode 'CONT', a measurement in progress must be stopped.




- | | |
|--|--------------------------|
| 1. Set the averaging mode: | Averag.Mode: CONT |
| For smoothing a measured value | |
| select attenuation, if required: | Attenuate: 20 |
| In addition, switch the continuous measurement off: | ConvRate: 10 Cont: - |
| 2. Clear the average value by selecting it and using: | <CLR> |
| Function 'Average Value' \bar{M} displays: | AverageVal: -----ms |
| Function 'Count' displays: | Count: 00000 |
| 3. Manual scans of measured values: | <MANU> |
| Function 'Average Value' \bar{M} zeigt: | AverageVal: 12.34ms |
| Function 'Count' displays: | Count: 00001 |
| 4. Repeat step 3 for each measuring point. | |
| 5. Output of all function values of the menu by using: | <PRINT> |

6.4.4 Averaging over Cyclic Measuring Point Scans

Continuous averaging

Again, the averaging mode 'CONT' must be used if the average value over the whole measurement is only required at the end of cyclic meas. point scans.



Setting the averaging over all measuring point scans: Averag.Mode: CONT
 Programming the print cycle (see 7.2): PrintCycle:00:15:00 U

Automatic clearing of average val. on start (see 10.8)

or, after selecting the average value, by using: <CLR>

Start measurement, averaging in progress: <START> **Check:** ▶ **M**
 Stopping the measurement: <STOP> II


Reading the average value \bar{M} in function 'Average Value': AverageVal: 13.24ms

Reading the number of averaged values in function: Count: 00123

Output of all function values of the menu by using: <PRINT>

Cyclic averaging

The averaging mode 'CYCL' must be used if average values have to be acquired in cyclic periods over these periods. This ensures that the average values are cleared after each print cycle. Furthermore, either the continuous measuring point scan or a measuring cycle must be activated to obtain measured values within the print cycle for determining average values.



Setting the averaging over cycles: Averag.Mode: CYCL
 Programming the print cycle (see 7.2): PrintCycle:00:15:00 U
 Switching on the continuous measurement: ConvRate: 10 Cont: ✓
 or programming the measuring cycle (see 7.2): Meas.Cycle:00:00:30 U


For recording the average values an additional **function channel** with the range M(t) (see manual 6.3.4) or the corresponding **output function** M(t) (see manual 6.10.4) is required instead of the measured value.



6.4.5 Averaging over Time

To acquire the average value of all meas. values over a defined period without cycle, the averaging mode 'STSTP' must be set for the selected measuring channel. For example, by uniformly scanning an area, this mode also allows to determine the average flow velocity in a ventilating channel (see manual 3.5.5).

A measuring point scan will be performed on start and stop allowing to record the start and end values including the time of day. Again, a function channel $\overline{M}(t)$ is required for the average value \overline{M} .



If the continuous meas. point scan (see 8.3) is activated, all sensors will be considered with a correspondingly reduced conversion rate, if it is switched off, only the selected channel will be acquired with the actually set conv. rate:

As required, de-/activation of cont. meas. point scan: ConvRate: 10 Cont: -

Set the averaging mode: Averag.Mode: **STSTP**

Automatic clearing of average val. on start (see 10.8)

Check:

or, after selecting the average value, by using:

<CLR>

Starting the averaging using the key:

<START> ▶ **M**

Reading the meas. time (see 6.4.6) in function:

MeasTime: 00:01:23.40

Stopping the averaging using the key:

<STOP> ||

Reading the average value \overline{M} in function:

AverageVal: 13.24ms

Output of all function values of the menu by using: <PRINT>

6.4.6 Measurement Time

For the averaging over time (see above) and for many other measurement experiments, in many cases, the actual measurement time, from start to stop, is required. The function 'Meas.Time' has a resolution of 0.10s and is available to allow a continuous monitoring of the measurement time without clearing the real time. If the function 'Clear Meas. Values On Start of a Measurement' is activated within the operating parameters (see 10.8), the measurement time will also be automatically cleared on each start.

Function 'Measurement Time': MeasTime: 00:00:00.00

Clearing the meas. time in function 'Meas.Time' by using: <CLR>


The time of day must be cleared before start (see 7.1) if the measurement time should also be displayed at measuring point scans with output to the interface or memory.



6.4.7 Volume Flow Measurement

To calculate the volume flow in a flow conduit the extra functions 'Diameter', 'Cross Section' and 'Volume' are available. Together with the averaging functions they are organised in the menu 'Flow', which can easily be loaded or individually configured as a user menu by using the software AMR-Control (see 6.6).

As unstable measured values can be easier read out when an analog display is used, this menu, besides a small digital display, also provides a **bar chart**.



The display range of the bar chart can be set by using the functions '**Analog Start**' and '**Analog End**' in the menu 'Special Functions' (see 9.10.4). The menu is automatically called up if the corresponding values below the scale are selected.

For **determining the volume flow** VF in ventilating channels the average flow velocity \bar{v} has to be multiplied with the cross section area CS:

$$VS = \bar{v} \cdot QF \cdot 0.36$$

$$VS = m^3/h, \bar{v} = m/s, QF = cm^2$$

For rough air volume measurements at air vents the **average flow velocity** \bar{v} can be determined by a **time-based averaging** (see 6.4.5 and manual 3.5.5). The rotating vane must be applied at one end, the averaging has to be started and it is necessary to proceed uniformly over the whole cross-sectional area and to stop the averaging when the other end of the cross-sectional area is reached.

Alternatively, the average flow velocity can also be determined by single **net measurements** according to VDI/VDE 2640 (see 6.4.3 and man. 3.5.5) (e.g. 13.24 m/s).

The average velocity \bar{v} can be displayed through function: AverageVal: 13.24ms
 Input of the cross section area CS directly in cm^2 : CrossSection: 00175cm
 (max. 32000 cm^2)
 or input of the diameter in mm: Diameter: 00150mm
 (max. 2000 mm)
 Display of the volume flow VF in m^3/h in function: Volume: 00834mh
 Output of all function values of the menu by using: <PRINT>

For outputting and storing the number of measuring operations and the volume flow, the function channels 'n(t)' and 'Flow' are now also provided; (see Section 9.9).

6.5 Display of Several Measuring Points

The first three measurement menus allow, on principle, only the selection and display of one measuring point. This chapter provides a description on how you can get up to four measuring points with your selection of functions, or even up to 20 measuring points simultaneously on the display.


6.5.1 Menu Multi Channel Display

After the first call the standard menu 'S3 Multi Channel Display' indicates the first three channels of the first connector:

In the user menu U3 '4 Bar Chart' four channels will be displayed with measured value and bar chart.



Remember to switch on the continuous measuring point scan ('C') to ensure that the measured values will be continuously updated.



Measuring point selection :

The 1st measuring channel is always the selected measuring point.

This can be selected directly in any menu, by means of : <M▲>.

To change the other channels, the measuring point must be selected as function, by means of keys (see above) : PROG, <F▲>.

The selected measuring point can now be changed by means of : <M▲>.

The process of measuring point selection is terminated by pressing key : ESC.

In the standard menu S3 only three of the four measuring points are displayed.

This is because of the size of the measured value display and the additional functions. As described in Section 6.6, this menu can also be configured individually by the user as U3 to include other measured value displays and / or other functions.



With all measured value functions (e.g. maximum, average, and bar chart), the measured value of the measuring point must always be entered first and then the associated functions !

The functions 'Setpoint' and 'Attenuation' are available for the selected measuring point (1st channel) once only.

The functions 'Set to zero' and 'Adjust' cannot be accessed via this menu.

6.5.2 Menu List of Measured Values

The best overview of the meas. system incl. all meas. points, time of day, date, meas.cycle and print cycle is obtained with the menu '**MeasValList**'.



Remember to switch on the continuous measuring point scan ('C') to ensure that the measured

values will be continuously updated.

This menu cannot be individually configured, it can only be combined with some selected functions:

C ▶	REC	COM	>>	R01	■ □
MeasValList: Name					
	12:34:56			01.02.00	
M:	00:00:00	S	P:	00:12:34	U
00:	23.12°C		Temperat.		
01:▲	87.3°C		NiCr		
02:	123.4mV		U2.4		
10:	67.5%H		Humidity		
20:	15.2°C		Dew Point		
30:	11.2gk		Mixture		
FCT PRINT START MANU					

At the first call a list with max meas. points is displayed MeasValList: 20 MPTs

It is not possible to display more than 20 channels. 00: 23.12°C



Functions can be allocated to a measured value by using: <FCT>

This reduces the max. number of channels to 10.

The following function:

<FCT>

Measured value including **comment**:

MeasValList: Name

Measured value including **max value**:

00: 23.12°C Temperature

Measured value including **min value**:

MeasValList: MaxVal

00: 23.12°C 32.67°C

Measured value including **average value**:

MeasValList: MinVal

00: 23.12°C 19.34°C

Measured value including **limit value Max**:

MeasValList: AvgVal

00: 23.12°C 25.45°C

Measured value including **limit value Min**:

MeasValList: LV-Max

00: 23.12°C 32.67°C

Measuring range only (max. 20 channels):

MeasValList: LV-Min

00: 23.12°C 19.34°C

MeasValList: Range

00: NTC °C

Switching to the previous function:

press and hold <FCT>

Further channels can be displayed by

leafing through the list :

PROG, <M▲>, or <M▼>.


The programming functions


can be accessed as follows :

PROG, <F▲/▼>, PROG.

6.6 Configuration of User Menus

When studying the measurement menus you may have noticed that the display of the measured value and the combination of functions does not always match your applications in an optimum way. Therefore, the ALMEMO® 2590-9 allows you to freely configure three individual user menus, U1 to U3, in addition to the three standard menus, S1 to S3. You can use the following list of functions to individually place the functions you require, in any sequence, on your display up to the available space of 13 lines. In addition to the measuring functions that have been described before, it is possible to use times and cycles for the process control (see 7.) and most of the sensor programming functions (s. 9.).

Functions:	Display:	Keys:	Command:
Limit value Max (s. 9.5)	LimValMax: 1234.5°C	OFF ON	o 00
Limit value Min	LimValMin: -0123.4°C	OFF ON	o 01
Base value (s. 9.6)	BaseVal: -----	OFF ON	o 02
Factor	Factor: 1.12345	OFF ON	o 03
Zero point (s. 9.7)	ZeroPoint: -----	OFF ON	o 04
Slope (gain)	Slope(Gain): -----	OFF ON	o 05
Analog start (s. 9.10.4)	AnalogStart: 0.0°C	OFF ON	o 06
Analog end	AnalogEnd: 100.0°C	OFF ON	o 07
Range (s. 9.9)	Range: NiCr		o 08
Max value (s. 9.1.3)	MaxVal: 1122.3°C	CLR CLRA	o 09
Min value	MinVal: 19.3°C	CLR CLRA	o 10
Average value (s. 6.4)	AverageVal: -----	CLR CLRA	o 11
Print cycle (s. 7.2)	PrintCycle: 00:00:00nU	CLR FORM	o 12
Meas. cycle (s. 7.3)	MeasCycle: 00:00:00 S	CLR	o 13
Time, date (s. 7.1)	12:34:56 01.02.00	CLR	o 14
Meas. value small (s. 6.4)	00:234.5°C Temperature	ZERO ADJ	o 15
Meas. value medium (s. 6.) 3 lines	00: 1234.5°C	ZERO ADJ	o 16
Meas. value large (s. 6.) 7 lines	00: Temperature °C 1234.5		o 17
Meas. value bar (s. 6.4) 2 lines (meas. range s. 9.10.4)	 5.00 S220 ms 15.0	ZERO ADJ	o 34

Functions:	Display:	Keys:	Command:
Graphic (see 6.2.4) full screen		TIME SCALE	o 35
Averaging mode (s. 6.4.2)	Averag.Mode: CONT	CLR	o 18
Conversion rate: (s. 7.4)	ConvRate: 10 Cont: ✓	OFF ON	o 19
Print timer: (s. 6.2.3)	PrintTimer: 00:00:00nU	CLR FORM	o 20
Meas. timer:	MeasTimer: 00:00:00 S	CLR	o 21
Averaging count (s. 6.4.3)	Averag.Count: 00000.		o 22
Number (s. 8.3)	Number: 123456	OFF ON	o 23
Range, comment:	NiCr Temperatur M H↗		o 24
Diameter mm (s. 6.4.7)	Diameter: 00000mm	CLR	o 25
Cross section cm ² (s. 6.4.7)	CrossSect: 00000cm	CLR	o 26
Volume m ³ /h (s. 6.4.7)	Volume: 00000mh		o 27
Max-time-date (s. 6.1.2)	MaxTime: 12:34 01.02.		o 28
Min-time-date (s. 6.1.2)	MinTime: 13:45 01.02.		o 29
Blank line:			o 30
Line:			o 31
Attenuation (s. 6.4.1)	Attenuation: 10	CLR	o 32
Memory free (s. 8.2)	MemoryFree: 502.1kB	CMEM PRINT	o 33
Device designation (s.10.1)	SampleMan Corporation	CLR	o 36
Text1: (s. 6.6.2)	1: CommentLine	CLR	o 37
Text2:	2: CommentLine	CLR	o 38
Text3: (s. 6.6, 6.6.2)	U1 MenuTitle	CLR	o 39
Text4:	U2 MenuTitle	CLR	o 40
Text5:	U3 MenuTitle	CLR	o 41
Locking (s. 9.4)	Locking: 5	CLR	o 42
Atm. pressure (s. 6.3.4)	AtmPress: 1013mb	CLR	o 43
Temperature comp.(s. 6.3.3)	TempComp: 25.0°C	CLR	o 44
Setpoint (s. 6.3.2)	SetPtVal: 1100.0°C	OFF ADJ	o 45
Meas. time: (s. 6.4.6)	MeasTime: 00:00:00.00	CLR	o 46
End of menu:			o 99

How do I configure my menu?

Activate the user menus U1 to U3 by using the key: <S/U>

Select the user menu U1, U2 (for one measuring point only) or U3 (for max. 4 meas. points), which suits your application best.

<F▲> / <F▼>, PROG

Then, the easiest way to configure the menu is to use a PC and the drag and drop function of the AMR-Control **software**. The selection is based on the device list.

Devices

List

Program user menus

Alternatively, you can program the menu using the **keypad**:

Firstly, you press and hold the key:

press and hold PROG

E.g., with menu U1 the following list is displayed:

```

00: Blank line
01: Text 3
02: Meas. val. average
03: Range, comment
04: Blank line
05: Locking
06: Setpoint
07: Zero point
08: Factor
09: TempComp
10: AtmPress
11: End
12:
    
```

Selection of the first function using the key:

PROG

Programming the function:

PROG

Blank line

Selection of the functions using the keys:

<▲> or <▼>

Storing the function using the key:

PROG

Selection of the next line, programming, as above:

<F▼>, PROG etc.

Terminating the menu configuration using the keys:

ESC, ESC

After the configuration of the user menus is complete

the **main menu** provides the following options:

Programming of the title of the selected user menu:

press and hold PROG


Text input in main menu or user menu, see 5.5

U1 MeasCorr.

Switching over between **standard** and **user** menus:

<S/U>

In most cases, by using the **operating dial** the whole configuration can be performed much faster.



6.6.1 Function Printouts

The functions of all measurement menus can be printed out in the listed sequence by using the key: <PRINT> (cf. 6.1.3)
The print format of the individual functions is given in the following table:

Function	Printout
Meas. Val. all	01: +0023.5 °C Temperature
Maxvalue	MAXIMUMVALUE: 01: +0020.0 °C
Maxtime	MAXTIME: 01: 12:32 01.02
Minvalue	MINIMUMVALUE: 01: -0010.0 °C
Mintime	MINTIME: 01: 12:32 01.02
Average Value	AVERAGEVALUE: 01: +0017.8 °C
Averaging Mode	AVERAG.MODE: 01: CONT
Averaging Count	AVERAG.COUNT:01: 00178.
MemoryFree	MEMORY: S0512.1 F0324.4 A
Number	NUMBER: 01-012
Range (Comment)	RANGE: 01: NiCr
Limit Value Max	LIMVAL MAX: 01: -0100.0 °C
Limit Value Min	LIMVAL MIN: 01: +0020.0 °C
Base	BASEVAL: 01: -0273.0 °C
Factor	FACTOR: 01: +1.0350E-1
Zero Point Correct.	ZEROPOINT: 01: -0000.7 °C
Slope Correction	SLOPE: 01: +1.0013
Analog-Start	ANALOGSTART:01: +0000.0 °C
Analog-End	ANALOGEND: 01: +0100.0 °C
Druckzyklus	PRINTCYCLE: 00:06:00
Meas. Cycle	MEASCYCLE: 00:01:30
Print Timer	PRINTTIMER: 00:06:00
Meas. Timer	MEASTIMER: 00:01:30
Time, Date	TIME: 12:34:00 01.02.00
Start Time	STARTTIME: 07:00:00
End Time	ENDTIME: 17:00:00
Start Date	STARTDATE:01.02.99
End Date	ENDDATE: 02.02.99
Meas. Time	MEASTIME: 00:00:00.00
Attenuation	ATTENUATION: 01: 10
Diameter	DIAMETER: 01: 00100 mm
Cross section	CROSSSECTION: 01: 00078 cm2
Volume flow	VOLUME: 01: 00000 m3/h
Atm. pressure	ATMPRESS: 01: +01013.mb
Temp. compensation	TempComp: 01: 25.0°C
Setpoint	Setpoint: 01: 1100.0°C
Device designation	Fa.Ahlborn,Holzkirchen
Line	-----
Blank line	
Text1	CommentText 1

Function	Printout
Text2	CommentText 2
Text3	MenuTitle U1
Text4	MenuTitle U2
Text5	MenuTitle U3
Locking	Locking: 5

6.6.2 Programming via the Serial Interface

Only new commands, which are not covered by the manual section 6, will be listed in the following.

Selecting the line xx: ixx

Selection of menu u and function yy: fu oyy

Entering the texts: Text 1: f5 \$Text1

Text 2: f6 \$Text2

Text 3=MenuTitle U1: f7 \$Text3

Text 4=MenuTitle U2: f8 \$Text4

Text 5=MenuTitle U3: f9 \$Text5

Output of the texts 1 to 5:

f5 P20

Text1 etc.

Output of the menu configurations:

fu P20

Menu title of the menu u

U1:MenuTitle U1

In line 00: function yy

00:30

In line 01: function yy

01:39

....

02:16

03:24

04:30

05:42

06:45 ...

Output of all functions of the selected menu
(print format see 6.6.1):

P20

Menu title

Meas.Correct.

Meas. value average

00: +025.67 °C

RANGE: 00: Ntc

Blank line

LOCKING:0.

SETPPOINT: 00: +0000.0 øC

COMPENSATION 00: +0000.0 øC

ATM.PRESS.: +01013. mb

Input of the cross-section area for the input channel in cm2 :

Cross-section Qxxxxx (max. 32000, see Section 6.4.7)

Input of the attenuation for the input channel : f1 zxx (see Section 6.4.1)

Input of temperature compensation in 0.1 °C : f1 gxxxxx (f1 G00150=15.0 °C)

7. Times and Cycles

Some time functions for the process control have been introduced. All associated functions are combined in the menu **'Times-Cycles'** and can also be programmed there.

* Times-Cycles *	
12:34:56	01.02.00
PrintCycle:	00:00:00
Storing:-	Sleep:-
Output Format:List	
Meas.Cycle:	00:12:34
Storing:-	
ConvRate:	10 Cont: ✓
Storing:-	
Output:-	
StartTime:	07:00:00
StartDate:	01.02.00
EndTime:	17:30:00
EndDate:	01.02.00
PRINT	

7.1 Time and Date

The ALMEMO® 2590-9 is equipped with a real time clock with date function for recording the measuring time. It has a lithium battery so the time and date are maintained after a switch-off. By selecting the function (see 5.4) the time can be programmed in the specified format in the first line on the left side and the date on the right side (see 5.5).

Function 'Time and Date': 12:34:56 01.05.00
 Format of time and date (e.g. 1. May 2000) hh:mm:ss dd.mm.yy

The year number can also be provided with 4 digits via interface (see 10.8 and manual 6.10.13).

7.2 Print Cycle with Storage Activation and Output Format

In most cases the print cycle is used for cyclic storage and outputs of measuring data. The storage activation, i.e. the recording of data in the memory within the print cycle is automatically switched on after a reinitialisation but it can also be switched off, if required.



Of course, it is not necessary that a peripheral device is connected to the socket A1 if the print cycle is used, e.g. for storing data.

The **output format** (see manual 6.6.1) determines the print format at measuring point scans and at the memory output. It is programmed by using the function 'Output Format'. Apart from the standard format 'List', with all measured values given in a list, the output format 'Columns' allows for a clear and space-saving printout in columns. For this purpose, a printer will automatically switch to the condensed character mode. Alarm lists during the measuring cycle are not available for this format. The **format 'Table'** is available to further process measuring data by means of spreadsheet applications (see manual 6.1).

Function 'Print Cycle' (format hh:mm:ss see 5.5): PrintCycle: 00:15:00
 Clear print cycle, terminate current scan: <CLR>

Function 'Storage Activation' in print cycle:

Switch on storing:

Switch off storing:

Store: ☒ Sleep: -

<ON>

✓

<OFF>

-



If, when using Win-Control to record a measured value, you want the data also saved on the device itself, you should activate the memory during the measuring cycle - because saving during the print cycle is automatically deactivated. As cycle the computer's measuring rate is sufficient; or you can use the measuring cycle.

Switch on function 'Sleep Mode', see 8.6:

<ON>

✓

Output format ' ' measured values in list format:

OutputFormat:List

Output format 'n' columns side by side:

OutputFormat:Columns

Output format 't' table with semicolon separation:

OutputFormat:Table

Output of date and time in Excel number format, see 10.8.

In the meas. menus the format abbreviations 'n' or 't' and 'S' (with storage activation) or 'U' (without storage activation) are displayed next to the print cycle:

PrintCycle:00:15:00nS

7.3 Measuring Cycle and Storage Activation

Generally, the measuring cycle is used for data acquisition within a print cycle, e.g. for the following applications:

1. Frequent data storage in measuring cycle, printing in print cycle only
2. Limit value monitoring and alarm value output in measuring cycle
3. Cyclic averaging (see manual 6.7.4)

Function 'MeasCycle' (format hh:mm:ss s. 5.5):

MeasCycle: 00:00:30

Clear meas. cycle, terminate current scan:

<CLR>

Function 'Storage Activation' in meas. cycle:

Store: ☒

Switch on storing:

<ON>

✓

Switch off storing:

<OFF>

-

7.4 Conversion Rate, Continuous Measuring Point Scan

If required, for measuring point scans the conversion rate can in function 'Conv.Rate' be increased from 2.5 up to 10M/sec or 50M/sec (see manual 6.5, 6.5.4).

The **continuous measuring point scan** (previously introduced) can at this point, be switched on or off by using the function 'CONT', i.e. either the selected measuring point will only be scanned, or all active measuring channels will be continuously and successively scanned (see manual 6.5.1.3). The following two functions can be used to activate the continuous storage and the continuous output of measuring data at the conversion rate.

Measuring rate function : for input (see Sec.5.5) Measuring rate : 10

Continuous measuring point scan (basic setting) : Cont : ✓

Continuous storage : Save : -

Activate continuous storage : <ON> ✓

Continuous output : Output : -

Activate continuous output : <ON> ✓

At the conversion rate of 50 measuring operations per second, the shorter evaluation times lead to the following restrictions :

1. The increased conversion rate only takes effect after a measuring operation has been initiated; before this, the device remains set at 10 measuring operations per second.

2. During measuring operations at a higher measuring rate, the ALMEMO connectors are no longer monitored; i.e. the connector configuration can only be modified when the measuring device has stopped.

3. Alarm value printout is not provided.

4. The analog output is not used.

5. At rates above 10 measuring operations per second, mains hum suppression is not provided; as a result, accuracy may be adversely affected by interference over the connection lines; (wherever possible use twisted wires !)

7.5 Time and Date of Start, Time and Date of End

A sequence of measurements can, at certain points in time, be automatically started and stopped. For this purpose the start time and date and the end time and date can be programmed. If a date has not been specified the measurement will be performed every day in the defined period. The current time must be programmed beforehand.

Function 'Start Time': StartTime: 07:00:00

Function 'End Time': EndTime: -----

Input (see 5.5) in format: hh:mm:ss

Function 'Start Date': StartDate: 01.05.00

Function 'End Date': EndDate: -----

Input (see 5.5) in format: dd:mm:yy

To clear values, select function and then use: <CLR>

If the start time of a measurement has been programmed, the status line will include the symbol: '▶'

If the end time of a measurement has been programmed, the status line will include the symbol: '▶|'

8. Data Memory

The basic information with regard to data storage in ALMEMO® devices is given in the manual section 6.9.

A new feature is the possibility of saving several measuring operations with different configurations; however, to use this facility the ring memory mode must not be set; (see Manual, Section 6.10.13.2). With each new start, the configuration is checked; if it has changed, the new configuration is saved. The measuring operation is also automatically assigned a number; (see Section 8.3). Each configuration requires a storage capacity of 808 bytes. As, on principle, only one configuration can be allowed in a measurement file, the memory output into a table format is cancelled with each new configuration. The next measurement must then be selected by its number or the time/date.

8.1 Memory Extension through Smart Media Card

As an option the data logger 2590-9 provides a slot for a standard Smart Media Memory Card with 8MB or 32MB memory space. As a result, the memory capacity is extended to 1,6 or 7,2 million measured values. Furthermore, it is often useful when the data logger can remain at one measuring location and data can just be taken on a memory device and evaluated somewhere else.



Please consider the following characteristics when using external memories:

- The function ring memory will not be supported.
- If the internal data memory contains data when connecting the external memory the message 'CMEM' will be displayed in the function 'No: -- Free' and prompt the user to delete the internal memory by using the key <CMEM>. If the data needs to be rescued the external memory must be removed again and the data must first be read out.
- Additionally, the external memory modules can be identified with a two-digit number.
It can easily be entered in function 'No: 00 Free:'.
- All measuring operations, including manual scans, must be terminated with <STOP>. Data not thus terminated may be saved in incomplete form or may be overwritten with the next measuring operation.
- Therefore, the external memory must not be removed when a measurement is in progress!

8.2 Data Acquisition

The parameters, which are required for the recording of measuring data, have already been described in the menu 'Times-Cycles' (see section 7).

1. Time and date
2. Print cycle with storage activation, sleep mode, see 8.6
3. Measuring cycle with storage activation
4. Conversion rate with storage activation
5. Time of start and end of a measurement

Most functions are listed in the menu 'Memory'.



However, here the start/end time/date are used to define a time frame at the memory output, not for the data recording!

C ▶	REC	COM	>>	R01	*	<div></div>
* Memory *						
Number:	01-001			A		
12:34:56	01.02.00					
M:00:00:00	S	P:	00:12:34	U		
Memory ext:	04.165MB					
No: 02	Free:	02.734MB				
RingMemory:	-					
OutputFormat:	Columns					
StartTime:	07:00:00					
StartDate:	01.02.00					
EndTime:	17:30:00					
EndDate:	01.02.00					
DISP PRINT START MANU						

Menu 'Memory':

Number :	(e.g. room 12, measuring point 1) (see Section 8.3)	NUMBER :	12-001 A
Time and date:		12:34:56	01.05.00
Meas. cycle and print cycle with storage activation :		M:00:00:00	S P:00:12:34 S
Conversion rate with storage activation:		ConvRate:	10 M/s CSU

Internally available memory capacity:	Memory int:0507.3kB
Available free memory space:	No: -- Free:0217.5kB
or when external memories are connected:	

Externally available memory capacity:	Memory ext:08.165MB
Number and memory space of the ext. memory:	No: 02 Free:02.734MB
Linear memory without overwriting of data:	RingMemory:-
Activate ring memory with overwriting:	<ON> ✓

Starting the recording using the key:

Manual single storing with key:

For control purposes the status line will indicated:

Stopping the cyclic recording:

Displaying the data memory (see 8.4):

Output of the memory via interface (see 8.5):



configuration is checked at each start and if it has changed a number is automatically allocated, indicating the current configuration with the first two digits (e.g. 02-000, see 8.3).

<START>

<MANU>

'REC'

<STOP>

<DISP>

<PRINT>The

8.3 Numbering of Measurements

For the identification of measurements or series of measurements it is possible to individually enter a number before starting. It will be used automatically (see above) if the configuration has changed. With the next measuring point scan it will be output or stored, respectively. This allows to also assign single measurements during a read-out to specific measurement locations or measuring points (see manual 6.7).

After selecting the function 'NUMBER' the 6-digit number is entered in the usual way (see 5.5). In addition to the figures 0 to 9 the characters A,F,N,P,- or _ (space) can be used. After the input the number is activated and next to it an 'A' will be indicated until the next cyclic or manual measurement will be stored.

Function Number: (e.g. room 12, meas. point 1) NUMBER: 12-001 A
Zero setting and deactivating the number with: <CLR>
Activating the number with the key: <ON> A
Deactivating the number with the key: <OFF>

8.4 Memory Display

One measuring point scan at a time can be indicated in list format on the display. During a measurement in progress you can either follow the latest one or jump to particular points in time and successively navigate through the record. If required, the parameters 'Number' or 'Start Time/Date' must first be entered in the menu 'Memory'.

Calling the memory display from the menu 'Memory': <DISP>

Selecting the function 'Memory Display':

Soft keys:

Jump to the start of the data memory:

Jump to the number from menu 'Memory':


Find start time/date (menu 'Memory'):

Jump to the end of the data memory:

```
* MEMORYDISPLAY *
BEGIN NO TIME END
<BEGIN>
<NO>
<TIME>
<END>
```

Menu 'MemoryDisplay':

At the end of the data memory the measurement in progress can be followed and, by using the keys <START>, <STOP> and <MANU> it can be started, stopped or single measurements can be performed.

```
C ► REC COM |>>| R01 * 
* MemoryDisplay *
Number: 01-001 A
12:34:56.00 01.02.00
00: 23.12°C Temperat.
01: ^ 87.3°C NiCr
02: 123.4mV U2.4
10: 67.5%H Humidity
20: 15.2°C Dew Point
30: 11.2gk Mixture

START MANU
```

8.5 Memory Output

The content of the data memory can, completely or in parts, be output to the serial interface. For each output one of the three available output formats 'List', 'Columns' or 'Table' can be used. The option to specify partial ranges is available as it is possible to set the start and end time of measurements and also possible to select the number of corresponding identified measurements. Furthermore, it is possible to selectively read just the alarm values (e.g. exceeding of limit values) out of the overall memory.



At the output format 'Table' the output will be cancelled, if the configuration has changed. For the output of the remaining data the corresponding number must be activated!

Menu 'Memory':

Setting the output format:

OutputFormat: List

In case of selecting a numbered measurement:

Enter number in function 'NUMBER' (see 8.3): NUMBER: 12-001 A

To select a time interval:

Enter the start time using the format 'hh:mm:ss': StartTime: 07:00:00

Enter the end time using the format 'hh:mm:ss': EndTime: 17:00:00

Enter the start date using the format 'dd:mm.yy': StartDate: 01.05.00

Enter the end date using the format 'dd:mm.yy': EndDate: 01.05.00

Selecting the memory output:

<PRINT>

Selecting the function 'Memory Output':

* MEMORY OUTPUT *

Soft keys:

ALL NO TIME ALARM

Perform complete output of data memory:

<ALL>

Output of a numbered measurement:

<NO>

Output of a time interval from start to end:

<TIME>

Output of alarm values only:

<ALARM>

Menu 'Memory Output':

During the output of the data memory the parameters 'Number', 'Time' and 'Date' will be continuously updated.

In the function 'MemoryRest' the remaining memory content (in kB) to be output is continuously indicated.

```

C ► REC COM |>>| R01 * 
*      MemoryOutput      *
Number:      01-001 A
             12:34:56.00  01.02.00

Memory ext:  4420.5kB
No: 02 Free: 2107.4kB
MemoryRest:  1263.5kB
OutputFormat: Table

STOP MANU

```

Cancelling the memory output using the key: ESC
 Interrupting the memory output using the key: <STOP>
 The following options are available after an output interruption:
 Recall individual measured values: <MANU>
 Re-start the automatic output: <START>
 Cancelling the memory output using the key: ESC

After the memory output the device returns to the menu 'Memory'.

The memory contents will be output with the same print format as with a printer operation, including multiple printouts and different formats (see manual 6.6.1).

Print Format: MEMORY: 03 (evtl. connector number)
 NUMBER: 12-001 (if activated)
 DATE: 12.03.00

List format 12:30:00 01: +0012.0 °C NiCr Designation
 below each other 02: !+0008.8 °C NiCr Water
 03: >+125.00 °C Ntc MotorOil

The connector number of an external memory will be printed after each headline 'MEMORY'.

Clear Memory

Menu 'Memory':

Select function 'MemoryFree' (see 5.4): No: -- Free: 0217. kB

To clear the memory, first press the key: PROG

the memory capacity is highlighted: No: -- Free: kB

then the key: <CMEM>

Full mem. capacity is indicated as avail. mem. space: No: -- Free: 0507.5kB

Or cancel by using the key: ESC

8.6 Sleep Mode

For long term monitoring with larger measuring cycles it is possible to operate the measuring device in sleep mode. Within this power saving mode the device will be switched off after each measuring point scan and will be automatically switched on for the next measuring point scan after the cycle time has expired. This procedure allows, with one full charged battery to perform approximately 7000 measuring point scans. At 15 minutes for one cycle this results in a total measuring time of more than 70 days.

To save energy only the display will be switched off if the print cycle is shorter than two minutes or if, additionally, the measuring cycle or the continuous measuring point scan has been programmed. In this energy saving mode the operating time of the device is extended to approximately 65 hours for one battery pack.

The following steps must be carried out in the menu 'TIMES-CYCLES' to perform a **data recording in the true sleep mode**:

1. Clear the measuring cycle: MeasCycle: 00:00:00
2. Switch off the continuous measuring point scan: ConvRate: 10 Cont: -
3. Enter a print cycle with a min. duration of 2 minutes: PrintCycle: 00:05:00
4. Switch on the storage activation in the print cycle: Store: ☒ Sleep: -
5. Select the sleep mode: Store: ☒ Sleep: ☒
6. Switch on the sleep mode using the key: <ON> ✓
7. In a meas. menu, start Measure by pressing key : <START>
The device switches off, for control purposes lamp 'SLEEP' flashes only the lamp **'SLEEP'** flashes regularly.



The start or stop through start and end time or through limit values is, on principle, not possible in sleep mode and, therefore, must be switched off!

8. Within the set cycle the device switches automatically on, performs a measuring point scan, and then switches off again.
9. **Terminating the sleep mode:**
Use the sliding switch (1) to switch the device off and then on again. **ON - OFF - ON**
10. Terminate measurement by pressing the key: <STOP>

If the requirements 1 to 4 are not met, on start of a measurement, the device will not enter the sleep mode but only the switching off the display.

The **SLEEP** lamp flashes more quickly than when in "sleep" mode.

SLEEP lamp flashes.

8. Switching the display on again by using the key: **ESC**



If one minute expires without any key being pressed the display will switch off again!

9. Terminate measurement by pressing the key: <STOP>

9. SENSOR PROGRAMMING

As all ALMEMO® instruments contain the whole sensor programming stored in the ALMEMO® connector plug, the user, usually, does not need to perform any programming. Only if, for example, sensor errors must be corrected or existing sensors must be scaled or limit values need to be specified the comprehensive programming options have to be used.

If the corresponding sensor connector is connected all parameters of a channel can be checked and entered or changed via keypad in the menu 'Sensor Programming'. It must be considered that standard sensors are, by a locking mode, protected against unintentional modification and that the locking level must first be reduced before desired changes can be performed (see 9.2).

```

*   SENSOR PROGRAMM   *
Connector:0 Chann.:00
Comment: Temperature
Averag.Mode:  -----
Locking:           5.
7LimValMax:       35.0°C
  LimValMin:       -----
5BaseValue:       -----
  Factor:          -----
  Exponent:        0
4Zero Point:      -----
  Slope:           -----
2Dimension:       °C
1Range:  Diff 01-00
MALL PRINT M▲ M▼
  
```

Output of the sensor programming of all active measuring points (command P15 see man. 6.2.3) by using the key:

<PRINT>

9.1 Selecting the Input Channel

To query or to program the parameters of a sensor, it is first necessary to select the menu 'Sensor Programming' and then to set the required input channel by using the key M▲ or M▼. For this, only connected sensors and activated channels will be considered. To be able to activate new channels, the key 'MALL' must be used to enable the selection of **all** channels. The key 'MACT' can be used to reduce the selection back to the **active** channels only. The corresponding connector number will be displayed with each input channel.



When changing the input channel, the selected meas. point will not be changed, i.e. a measurement in progress will not be interrupted.

Menu 'SensorProgramming'	* SENSORPROGRAMM *
Indication of connector number and input channel:	Connector:0
Channel:00	
Selecting the next input channel using the key:	<M▲>
Selecting the previous input channel using the key:	<M▼>
Enabling the selection of all available channels:	<MALL>
Reducing the selection to all active channels:	<MACT>

9.2 Measuring Point Designation

Each measuring point can be given a 10-digit alphanumeric designation to optimally identify the type of sensor, the measuring location or the purpose of the application. This comment will be indicated with all standard displays of measured values. If it has not been programmed, the abbreviation of the measuring range will be indicated. In case of outputs via interface the measuring point designation appears in the program header as 'COMMENT' and in the list of measured values (see man. 6.6.1).



Input in function 'Comment', see 5.5 Comment: Temperature
It is possible, by means of comment " *J ", to overwrite the internal cold junction compensator and define a specific temperature sensor (Ntc, Pt100) as external cold junction compensator to apply to all channels; (see Manual, Section 6.7.3). It is now also possible (a new feature), by means of comment " #J ", to define, via the reference channel, a specific cold junction sensor (e.g. connector ZA9400-FSx with Ntc) to apply to just one thermocouple.

9.3 Averaging Mode

The types of averaging, which are defined through the function 'Averaging Mode', are described in section 6.4.2.

Function 'Averaging Mode' no averaging:

Averag.Mode: -----

9.4 Locking the Programming of the Sensor see man. 6.3.12

The function parameters of each measuring point are protected by the locking mode up to an adjustable locking level. Before any programming is performed the locking mode must be correspondingly lowered. If a dot is indicated following the locking mode on the display then a modification is not possible.

Locking Level	Locked Functions
0	none
1	Meas. range + element flags
3	+ Dimension
4	+ Zero point and gain (slope) correction
5	+ Base value, factor, exponent
6	+ Analog output, start and end
7	+ Limit values, max and min

Function 'LockingMode':

Locking: 5

In the menu 'Sensor Programming' the functions are arranged from top to bottom so that the locked functions cannot be selected. The menu and keypad locking must be used to protect the programming and the process control during a measurement against unauthorised modification (see 5.6).

9.5 Limit Values

Two limit values (MAX, MIN) can be programmed and allocated to each measuring channel. An exceeding of limit values is handled as a fault, similar to an exceeding of meas. range limits and sensor breakage. On the display a corresponding arrow ▲ or ▼ will appear next to the measured value, the alarm relays will respond and the alarm values will be provided as output during the measuring cycle (see manual 6.3.9). The alarm condition will persist until the measured value has dropped below the limit value by the hysteresis. Generally, the hysteresis is set to 10 digits, however, it can be adjusted to values between 0 and 99 digits (see 10.7). The exceeding of a limit value can also be used to start or stop a measurement (see 9.10.4).

Function:

Limit value Max:	LimVal.Max: 123.4°C
Limit value Min:	LimVal.Min: -----°C
Switching off the limit value:	<OFF>
Switching on the limit value:	<ON>

9.6 Scaling, Decimal Point Setting

For indicating the electrical signal of a sensor as a measured value of a physical variable it is, in most cases, necessary to set a zero point shift and to perform a multiplication with a certain factor. The functions BASE and FACTOR are available for this. A detailed description of the scaling, including an example, can be found in the manual section 6.3.11.

Indicated value = (corrected measured value - BASE) x FACTOR.

The FACTOR can be programmed in the range from -2.0000 to +2.0000. For factors over 2.0 or under 0.2 a corresponding decimal point setting must be considered by entering the EXPONENT. The EXPONENT allows to shift the decimal point to the left (-) or right (+) as far as it can be indicated on the display and printer. An exponential presentation of the measured values is not possible.

Function 'Base Value' (input see 5.5):	BaseValue: -----
Function 'Factor':	Factor: -----
Function 'Exponent':	Exponent: 0

The correction arrow ↗ will be indicated as status of the measured value, if scaling values have been programmed and the actual measured value has been altered.

9.7 Correction Values

The correction values ZERO POINT and SLOPE (GAIN) allow for correcting sensors with regard to zero point and slope (gain) (see manual 6.3.10). .

Corrected Meas. Value = (Meas.Value - ZERO POINT) x SLOPE (GAIN)

Function:

Zero Point Correction:


ZeroPoint: -----°C

Slope correction:

Slope: -----°C

Switch on/off keys:

< OFF> or <ON>

The correction arrow  will be indicated as status of the measured value, if scaling values have been programmed and the actual measured value has been altered.

9.8 Changing the Dimension

Each measuring channel allows to replace the standard dimension of the measuring range by any other dimension that has two digits (see manual 6.3.5). In addition to all capital and normal letters, the characters ?(ohm), %, [,], *, -, =, ~ and spaces () are available. The dimension is indicated by two characters that are indicated next to the measuring and programming values.

The **dimension can be changed** using the function: Dimension: °C



When the dimension °F is entered a temperature value in degreeCelsius will be converted into degrees Fahrenheit. The cold junction compensation can be switched off by using the characters '!C'.

9.9 Selecting the Measuring Range

If users want to program the connectors on their own or if they frequently change the measuring range, it must be considered that the locking must be cleared, i.e. set to zero (see 9.4), and that special connectors may be required for some transducers (e.g. thermo, shunt, divider etc., see table). To activate a new measuring channel, activate all channels by using the key 'MALL', select the corresponding input channel (see 9.1) and then enter the measuring range. With the input acknowledgement of the new measuring range all programming values of the input channel will be cleared.

Function 'Meas. Range Selection':

RANGE: NiCr

Possibly, enabling the selection of all avail. meas. chann.:

<MALL>

Switch-off, i.e. deactivating a channel:

<CLR>

Switch-on, i.e. re-activating the channel:

PROG, PROG

Programming of range as with data input, see 5.5

PROG, <▲>.... , PROG

In the input window all abbreviations of

the following table are indicated successively:

RANGE: FECO

Transducer	Conn./Cable/ Sensor	Meas. Range	Dim	Display
Pt100-1	ZA 9000-FS	-200.0... +850.0	°C	P104
Pt100-2	ZA 9000-FS	-200.00...+400.00	°C	P204
Pt1000-1 (element flag 1)	ZA 9000-FS	-200.0... +850.0	°C	P104
Pt1000-2 (element flag 1)	ZA 9000-FS	-200.00...+400.00	°C	P204
Ni100	ZA 9000-FS	-60.0... +240.0	°C	N104
NiCr-Ni (K)	ZA 9020-FS	-200.0...+1370.0	°C	NiCr
NiCroSil-NiSil (N)	ZA 9020-FS	-200.0...+1300.0	°C	NiSi
Fe-CuNi (L)	ZA 9000-FS	-200.0... +900.0	°C	FECO
Fe-CuNi (J)	ZA 9000-FS	-200.0...+1000.0	°C	IrCo
Cu-CuNi (U)	ZA 9000-FS	-200.0... +600.0	°C	CUCO
Cu-CuNi (T)	ZA 9000-FS	-200.0... +400.0	°C	CoCo
PtRh10-Pt (S)	ZA 9000-FS	0.0...+1760.0	°C	Pt10
PtRh13-Pt (R)	ZA 9000-FS	0.0...+1760.0	°C	Pt13
PtRh30-PtRh6 (B)	ZA 9000-FS	+400.0...+1800.0	°C	EL18
Au-FeCr	ZA 9000-FS	-270.0... +60.0	°C	AUFE
Ntc Type N	ZA 9000-FS	-30.00...+125.00	°C	Ntc
Millivolt 1	ZA 9000-FS	-26.000...+26.000	mV	U 26
Millivolt	ZA 9000-FS	-10.000...+55.000	mV	U 55
Millivolt 2	ZA 9000-FS	-260.00...+260.00	mV	U260
Volt	ZA 9000-FS	-2.6000...+2.6000	V	U2.60
Differential Millivolt 1	ZA 9050-FS	-26.000...+26.000	mV	d 26
Differential Millivolt	ZA 9050-FS	-10.000...+55.000	mV	d 55
Differential Millivolt 2	ZA 9050-FS	-260.00...+260.00	mV	d260
Differential Volt	ZA 9050-FS	-2.6000...+2.6000	V	d2.60
Sensor voltage	ZA 9000-FS	0.00...20.00	V	UbAt
Milliampere	ZA 9601-FS	-32.000...+32.000	mA	I032
Percent (4-20mA)	ZA 9000-FS	0.00... 100.00	%	P420
Ohm	ZA 9000-FS	0.00... 400.00	Ω	Ohn
Frequency	ZA 9909-AK	0... 25000	Hz	FrEq
Pulse	ZA 9909-AK	0... 65000		PULS
Digital input	ZA 9000-EK2	0.0... 100.0	%	Inp
Digital interface	ZA 9919-AKxx	-65000... +65000		diGi
Infrarot 1	ZA 9000-FS	0.0... +200.0	°C	Ir 1
Infrared 4	ZA 9000-FS	-30.0... +100.0	°C	Ir 4
Infrared 6	ZA 9000-FS	0.0... +500.0	°C	Ir 6
Snap-on head Normal 20	FV A915-S120	0.30... 20.00	m/s	S120
Snap-on head Normal 40	FV A915-S140	0.40... 40.00	m/s	S140
Snap-on head Micro 20	FV A915-S220	0.50... 20.00	m/s	S220
Snap-on head Micro 40	FV A915-S240	0.60... 40.00	m/s	S240
Macro	FV A915-MA1	0.10... 20.00	m/s	L420
Water-Micro	FV A915-WM1	0.00... 5.00	m/s	L605
Dyn. press. 40m/s with TC a. PC	FD A612-M1	0.50... 40.00	m/s	L840

Transducer	Conn./Cable/ Sensor	Meas. Range	Dim	Display
Dyn. press. 90 m/s with TC a. PC	FD A612-M6	1.00... 90.00	m/s	L890
Rel. humidity cap.	FH A646	0.0... 100.0	%H	°o rH
Rel. humidity cap. with TC	FH A646-C	0.0... 100.0	%H	HcrH
Rel. humidity cap. with TC	FH A646-R	0.0... 100.0	%H	H rH
Mixture ratio with PC	FH A646	0.0 ... 500.0	g/kg	H AH
Dew point temperature	FH A646	-25.0... 100.0	°C	H dt
Partial vapour pressure	FH A646	0.0...1050.0	mbar	H UP
Enthalpy with PC	FH A646	0.0 ... 400.0	kJ/kg	H En
Humid temperature	FN A846	-30.00...+125.00	°C	P Ht
Rel. humidity psychr. with PC	FN A846	0.0 ... 100.0	%H	P RH
Mixture ratio with PC	FN A846	0.0 ... 500.0	g/kg	P AH
Dew point temperature with PC	FN A846	-25.0 ... +100.0	°C	P dt
Partial vapour pressure with PC	FN A846	0.0 ...1050.0	mbar	P UP
Enthalpy with PC	FN A846	0.0 ... 400.0	kJ/kg	P En
Conductivity probe with TC	FY A641-LF	0.0 ...20.000	mS	LF
CO ₂ sensor	FY A600-CO2	0.0 ... 2.500	%	CO2
O ₂ saturation with TC a. PC	FY A640-O2	0 ... 260	%	O2-S
O ₂ concentration with TC	FY A640-O2	0 ... 40.0	mg/l	O2-C
Function channels				
Difference (Mb1-Mb2)	any			diFF
Maximum value (Mb1)	any			Hi
Minimum value (Mb1)	any			Lo
Average value over time (Mb1)	any			A[t]
Av. val. over meas.pts (Mb1..Mb2)	any			A[n]
Sum over meas.pts (Mb1..Mb2)	any			S[n]
Total pulse count (Mb1)	ZA 9909-AK2	0... 65000		S[t]
Pulse count/print cycle (Mb1)	ZA 9909-AK2	0... 65000		S[P]
Alarm value (Mb1)	any			Alrm
Thermal coeff. $\overline{M}(q)/\overline{M}(M01-M00)$	ZA 9000-FS		W/m²K	q:dt
Wet bulb globe temp.	ZA 9000-FS		°C	UbGt

TC Temperature Compensation, PC Atmospheric Pressure Compensation

The **use of the function channels** for the output of measuring and calculated variables with the corresponding reference channels, Mb1 and Mb2, is described in the manual section 6.3.4. After the programming of the range the standard reference channels (1st channel in connector) are used: The individual configuration of the reference channels is described in the sections 9.10.6 and 9.10.7.

9.10 Special Functions

The data logger 2590-9 has a separate menu allowing access to all ALMEMO® special functions, which despite only rarely being required during routine operation, are very useful for some applications (see manual 6.10). These functions can (to a certain extent) be very complex and should only be used if their operation is completely understood.

```
* SPECIAL FUNCTIONS *
Connector:0 Chann.:00
PrintCycleFactor: 01
U-Sensor Min: 12.0 V
Action Max: Start R1
Action Min: End R2
Analog-Start: 0.0°C
Analog-End: 300.0°C
OutputFunction: MEAS
Ref.Channel 1: 01
Multiplexer: B-A
ElementFlags: IR
Cal.Offset: -12345
Cal.Factor: 43210
PRINT M▲ M▼
```

9.10.1 Print Cycle Factor

For the adaptation of the data recording to the update speed of the individual measuring points it is possible to program a print cycle factor between 00 and 99 to print measuring points less often or not at all (see manual 6.10.6). Only disturbed measuring points, e.g. on exceeding of limit values will always be output. Generally, the print cycle factor of all measuring points is cleared or set to 01, i.e. all activated measuring points will be printed at each print cycle. If a different factor, e.g. 10 is programmed, the corresponding measuring point will only be printed once in ten times, however, if 00 is programmed it will not be printed. The data recording within the print cycle also allows to suppress unnecessary measured values and, as a result, saves memory space.

Enter the print cycle factor (see 5.5) in function: PrintCycleFactor: 01

Clearing the print cycle factor with the key: <CLR>

9.10.2 Minimum Sensor Supply Voltage

Generally, the ALMEMO® devices monitor the sensor supply voltage, which, in most cases, corresponds to the operating voltage of the measuring instrument. It is also displayed in the device configuration (see 10.8). However, there are also sensors, which require for a correct operation a supply voltage, which requires a charged battery or a power supply unit. TO avoid measuring errors, the sensor programming allows to individually program the required minimum sensor voltage for each transducer. In case of falling below this voltage the measured value is treated as sensor breakage.

Entering the minimum sensor supply voltage: U-Sensor Min: 12.0 V

Switching off the voltage control, clearing the value: <CLR>

U-Sensor Min: ---- V

9.10.3 Limit Value Responses

Relay Allocation

As standard, both limit values of all measuring points of a device or of a measuring circuit board are used for fault alarms (see 9.5), i.e. if an exceeding of a limit value occurs at any measuring point, the relay 0 responds if an alarm relay cable or the corresponding relay adapter (see manual 5.2/3) is used. It only opens again, after all measured values have dropped below the limit values by as much as the hysteresis. If a limit value has not been defined, the measuring range limit will be used as limit value. A sensor breakage will always cause a fault alarm.

To distinguish between max value exceeding and min value undershooting the alarm signal generators can be re-programmed to variant 1 (see manual 6.10.9).

However, if it is necessary to selectively identify and evaluate faults, the function 'Response Max' or 'Response Min' can be used to allocate individual relays to the limit values. It is also possible to allocate several limit values to one relay. For this purpose the relay cables provide 2 relays (0 and 1) and the relay adapter (ZA 8000-RTA) provides 4 relays (0 to 3). This mode also has to be set as variant 2 in the output module (see manual 6.10.9).

Setting the relay module to variant 2:
(relay int. allocated)

Socket A2:
EA Trigger-Alarm
2: Rx int. allocated

Activating relay x at limit value exceeding Max:

Action Max: ----- **Rx**

Activating relay y at limit value undershooting Min:

Action Min: ----- **Ry**

Clearing the relay allocation using the key:

<CLR>

Starting and Stopping a Measurement

Exceeding of limit values can not only be used for fault alarms but also to start or stop a measurement (see manual 6.6.3). The start command or stop command is assigned to a limit value - by means of the 'Special functions' menu and function 'Action Max' or 'Action Min'.

Starting the meas. at exceeding of limit value Max: Action Max: **Start** --

Stopping the meas. at undershooting of lim.value Min: Action Min: **End** --

Clear response by using the key:

<CLR>

Beim Ausdruck der Fühlerprogrammierung (s. Hb. 6.10.1) erscheint bei Aktion Max (AH) und Min (AL) ein zusammengesetzter Code für Start/Ende S/E (s. Hb. 6.6.3) und Relaiszuordnung x (s. Hb. 6.10.8).

9.10.4 Analog Output Start and End

In most cases the analog output of measured values to the analog output modules (see manual 5) or the display as bar or line chart must be scaled to a specified sub-range. For this, it is just necessary to specify the start and end value of the display range required by you. This range is then mapped to the analog range 2V, 10V, 20mA or, for the display, to 100 dots.

Programming the **analog output start**: AnalogStart: 0.0°C
 Programming the **analog output end**: AnalogEnd: 100.0°C

These two parameters, analog output start and analog output end, are also stored in the EEPROM of the sensor and can, therefore, be individually programmed for each channel, i.e. during a manual switch through the channels an individual scaling is available for each measuring variable.

The flag for switching over from 0-20mA to 4-20mA can be programmed through the element flags (see 9.10.8).

9.10.5 Output Function

If not the real measured value but only the Max, Min, Average or Alarm value is required, then this function can be programmed as output function (see manual 6.10.4). As a result, only the corresponding function value will be considered for storing and analog or digital output. For control of the changed output function the symbol below is displayed next to the measured value (see 5.3).

Example:

1. If meas. values are averaged over the print cycle by means of the meas. cycle, only the average value is relevant as output value, but not the last measured value. This way, memory space can be saved in a data logger.
2. The analog measured value of the dew sensor FH A946-1 has no meaning. If the limit value Max is set to approximately 0.5V, and the measuring function 'Alarm Value' is programmed only the relevant values 0.0% for dry and 100.0% for 'dew' will be displayed.

Output Function	Control Symbol	Menu
Meas. value		OutputFunction: Meas
Difference	D	OutputFunction: Diff
Max value	H	OutputFunction: Max
Min value	L	OutputFunction: Min
Average value	M	OutputFunction: M(t)
Alarm value	A	OutputFunction: Alrm

9.10.6 Reference Channel 1

The arithmetic functions of the function channels, generally, refer to a particular measuring channel (or 2 meas. channels) (see manual 6.3.4). During the programming of a function channel the first channel of the corresponding sensor connector Mxx1 is automatically set as reference channel Mb1. The 2nd reference channel Mb2 (for difference etc.) is, initially, the measuring point M00. In function 'Ref. Channel 1' it is possible to set other measuring points as reference channel, either absolutely by specifying a particular measuring point or by specifying the 'distance' referred to the function channel (e.g. -01 identifies the channel preceding the function channel).

Programming of the ref. channel 1 absolute:	RefChannel 1:	01
Programming of the ref. channel 1 relative:	RefChannel 1:	-10

9.10.7 Reference Channel 2 or Multiplexer

In case of function channels, which require a second reference channel, the function 'Ref Channel 2' will automatically be displayed in the line after 'Ref Channel 1'. In all other cases it is possible to change the pin assignment in the connector by changing the input multiplexer (see manual 6.10.2).

Programming of the ref. channel 2 absolute:	RefChannel 2:	00
Programming of the ref. channel 2 relative:	RefChannel 2:	-01
Measuring inputs B+ and A-, GND-referred	Multiplexer:	B-A
Measuring inputs C+ and A-, GND-referred	Multiplexer:	C-A
Measuring inputs D+ and A-, GND-referred	Multiplexer:	D-A
Differential measuring inputs C+ and B-	Multiplexer:	C-B
Differential measuring inputs D+ and B-	Multiplexer:	D-B

9.10.8 Element Flags

For a realization of sensor-specific additional functions, element flags can be activated at each measuring channel (see manual 6.10.3).

Meas. current 1/10 for Pt1000, 5000Ω:	ElementFlags:	I 1/10
Emission and background temp. for IR sensors:	ElementFlags:	IR
Meas. bridge with switch for final value simulat.:	ElementFlags:	Bridge
(Activation base value:) *	ElementFlags:	Base
(Activation of all averaging functions:) *	ElementFlags:	Avg On
(Element flag 6:) *	ElementFlags:	Flag 6
Switch-off of the sensor breakage detection:	ElementFlags:	Br Off
Analog output 4-20mA instead of 0-20mA:	ElementFlags:	A 4-20

* At the ALMEMO 2590-9 these element flags have no meaning.

10. DEVICE CONFIGURATION

Some fundamental settings can be taken in the menu 'Device Configuration'. The device designation serves as print header in log printouts and facilitates the assignment within a network. Furthermore, the device address is imperative in a network. The baud rate can be adapted to external devices. Three modes are available for the illumination of the display. The setting of the atmospheric pressure for the compensation of certain sensors is particularly suitable at corresponding altitudes. The standard value of the hysteresis of alarm relays can be changed. For checking the device the channel number, sensor supply voltage and cold junction temperature are indicated.

```
*DEVICECONFIGURATION*
Device Designation:
Fa.Ahlborn,Holzkirchen
Device:00 2590-9 1.23X
BaudRate:          9600bd
Language:          English
Illumination:      -
Contrast:           50 %
AtmPress:           1013mb
Hysteresis:         10
Config:             FCRDAS67
MeasChann:40 active:05
Sensor Voltage:12.3 V
CJ-Temperat.: 25.4°C
```

PRINT

10.1 Device Designation

The function 'Device Designation' (see manual 6.2.4) allows to enter any text with max 21 digits (see 5.5). The text appears in the main menu, in the print header of a measurement and in device lists (software).

Function 'Device Designation':

Device Designation: Ahlborn,Holzkirchen

10.2 Device Address and Networking

All ALMEMO® instruments can be very easily networked to centrally acquire the measured values of several instruments that are located at different places (see manual 5.3). For communicating with networked devices it is mandatory that all devices have the same baud rate and an own individual address as only one device is allowed to respond to each command. Therefore, before any network operation it is necessary that all connected devices are set to different device numbers. For this, the function 'Device' is available. Generally, the device number 00 is set as the factory default value in this function. It can be changed by the usual data entry (see 5.5). For checking purposes it is followed by the device type, the version number and, possibly, an option code (see manual 6.10.11).

Function 'Device Address' with type and version: Device:00 2590-9 5.50X

Example: Address: 00, Type: 2590-9, Version: 5.50Q, Option: X

Only successive numbers between 01 and 99 should be entered for network operation so that the device 00 cannot be falsely addressed in case of a power supply failure.

10.3 Baud Rate, Data Format

All interface modules are factory-set and programmed to 9600 baud. To avoid unnecessary problems when networking several devices the baud rate should not be modified but the computer or printer should be set up accordingly. If this is not possible the values 300, 600, 1200, 2400, 4800, 9600bd, or 57.6, 115.2 kbd can be entered in the function 'Baud Rate' (please consider the max. baud rate of the interface module!). The baud rate setting will be stored in the EEPROM of the interface module and will then be valid for use with all other ALMEMO® devices.

Function Baud Rate: Baud Rate: 9600bd

Data Format: unchangeable 8 data bits, no parity, 1 stop bit

10.4 Language

The language of the function legend and the printouts can be set to German, French or English. The soft keys are international code and are not meant to be altered:

Language selection in function 'Language', see 5.5: Language: English

10.5 Illumination and Contrast

The background lighting of the display can be switched on or off in the main menu by using the key <*ON> or in the function 'Illumination' of the device configuration. If the illumination is switched on when a mains supply adapter is not connected, the illumination will switch off one minute after the last key was operated, and it will switch on again as soon as any key is operated. The following function allows to set the contrast to 10 different positions.

Switching the illumination on or off using <ON>, <OFF>:

Illumination: ✓

Switch-on **without** function by using the key:

ESC

The status line provides the symbol:

★ Pause:



Setting the contrast (10 to 100%), see 5.5:

Contrast: 50 %

10.6 Atmospheric Pressure

For compensation of various sensors the atmospheric pressure can be entered (see 6.3.5). If it is measured, it will also be indicated in this function:

Entering the atm. pressure in function 'Atm. Press.', see 5.5: Atm. Press: 1013mb

10.7 Hysteresis

In case of an exceeding of limit values the hysteresis of an alarm condition can, generally for all sensors, be set in the function 'Hysteresis' (see 9.5. and manual 6.2.7) within the range from 0 to 99 digits (standard setting is 10 digits).

Change hysteresis (0 to 99), see 5.5: Hysteresis: 10

10.8 Operating Parameters

Some operating parameters are software options and can be user-configured with the function 'Config' (see manual 6.10.13.2).

Mains frequency noise suppression 60Hz instead of 50Hz	Config:	F-----
Clearing all measured values on start of a measurement	Config:	-C-----
Ring memory (overwriting of old data when full)	Config:	--R-----
Year number output in date with 4-digits instead of 2-digits	Config:	---D----
Deactivating the alarm value/alarm printout	Config:	----A---
Switching off the signal transmitter	Config:	-----S--
Date-time in Excel table format 'dd.mm.yy hh:mm:ss'	Config:	-----E-

The following parameters can be used to check the device function:

The channel number can be configured, e.g. for hiding upper channels (see manual 6.10.13.1):

Out of 40 or 36, respectively, 5 channels are activated: Meas.Chann:40
active:05

Sensor supply voltage 12.3V = mains operation: SensorVoltage: 12.3 V
Cold junction temperature = socket temperature: CJ Temperature: 25.4°C

11. OUTPUT MODULES

The data logger ALMEMO® 2590-9 has two output sockets, A1 and A2, to allow an output of the measured values as analog or digital values or as alarm signals. Furthermore, it is possible to trigger various functions through trigger pulses. To suit all possibilities, while keeping the hardware requirements at a minimum, all necessary interfaces have been integrated into the ALMEMO® output connectors. The output modules, like the sensors, are automatically detected and displayed in the menu 'Output Modules' so that, generally, no programming is required.

* OUTPUT MODULES *	
Socket A1:	
DK Data Cable	
0: RS232	
Socket A2:	
EA Trigger Alarm	
2: Rx int. allocated	
Relay: 01-----	
Analog Chann: 00	
Analog Val: +32500	
PRINT	

11.1 Data Cable

The serial interface can be used to output cyclic data logs, all function values of the measuring menus, as well as the whole programming of the sensors and the device to a printer or computer. The ALMEMO® data cables and the connection to the instruments are described in the manual section 5.2. Other modules for networking the instruments follow in the manual section 5.3.

All available interface modules are connected to the socket A1(3), exception: network cables ZA1999NK to network a further instrum. are connected to A2.

Under the prevailing socket the menu indicates: **Socket A1:**
DC DataCable
 Variant 0: Standard interface always active **0: RS232**
 Variant 1: Activation in case of addressing **1: RS485**

11.2 Relay Trigger Cable

The combined input and output cables (ZA 1000-EAK) and the relay trigger analog adapter ZA 800x-RTA (see manual 5.1.2/3) provide max. 8 switching contacts for the triggering of peripheral devices and trigger inputs (see manual 6.6.4). They are connected to the output socket A2 and their function can be programmed (see manual 6.10.9):

Module	Type	No	Abbrev	Comment
Trigger cable	EK	0	EK0	Start/stop succession with pos. edge/contact
	EK	1	EK1	Single Measuring Point Scan
	EK	2	EK2	Clear Max/Min values
	EK	3	EK3	Print the function
	EK	4	EK4	Start/stop level-triggered
	NK	8	EK8	Setting the measured value to zero
Alarm cable	GK	0	AK0	Relay R0 alarm from all channels
	GK2	1	AK1	Relay R0 alarm Max, R1 alarm Min
	GK3	2	AK2	Relay Rx internally allocated (see 9.10.3)
	AK	8	AK8	Relay Rx externally triggered
Trigger alarm	EGK	0	EA0	Start/stop, relay R0 alarm from all channels
	EGK	1	EA1	Start/stop, relay R0 alarm Max, R1 alarm Min
	EGK	2	EA2	Start/stop, relay Rx internally allocated
	EAK	8	EA8	Start/stop, relay Rx externally triggered

A trigger alarm cable is connected to socket A2
 programmed to variant no. 2

Socket A2:
EA TriggerAlarm
2: Rx int. allocated

the relay R1 is activated

Relay: -1-----

After the function selection the variant can be programmed:

The alarm variant no. 2 'Relay internally allocated' additionally requires the **allocation of the relays** to particular limit values (see 9.10.3).

The variant no. 8 'Externally Triggered' allows a **manual triggering** of relays through the keypad or via the interface (see manual 6.10.10.)

Trigger alarm cable

EA TriggerAlarm

programmed to variant no. 8

8: Rx ext. triggered

Programming of the relay state, see 5.5

Relay: 0-----

11.3 ANALOG OUTPUT

For analog acquisition of the selected measuring point either an analog output cable ZA 1601-RK (see manual 5.1.1) without electrical isolation or a relay trigger analog adapter ZA 8000-RTA (see manual 5.1.3) with electrically isolated analog output can be connected to the sockets A1 or A2.

Scaling

It is possible to spread any partial range to the standard output signal of the three available options 0-2V, 0-10V, 0/4-20mA if the partial range covers at least 100 digits (e.g. 0-20mA for +200.0 to +1000.0°C). To achieve this, the required measuring range must be entered by using the functions 'Analog Output Start' and 'Analog Output End' in the menu 'Special Functions' (see 9.10.4).

These functions are also used to scale the line or bar chart.

Menu 'Special Functions'

Programming the analog output start:	AnalogStart:	0.0°C
Programming the analog output end:	AnalogEnd:	100.0°C

Selecting the Analog Channel

Usually, the measured value of the selected channel Mxx is output to the analog output. However, in case of a continuous measuring point scan a reference channel can be programmed allowing to define any channel for the analog output to socket A2. A second analog output to socket A1, simultaneously, outputs the measured value of the first channel of the selected sensor (see manual 6.10.7).

Analog output of the selected measuring channel Mxx:	AnalogChann:	Mxx
Analog output of the selected reference channel yy:	AnalogChann:	yy
Programmed analog output (see below):	AnalogChann:	M--

Programmed Analog Value Output

The analog value can also be programmed, manually or via interface, in a range from -12000...+20000 digits (see manual 6.10.7). Depending on the analog output the following output signals are available:

Voltage output	-1.2 ... +2.0 V	0.1mV/digit
Voltage output	-6.0 ... +10.0 V	0.5mV/digit
Current output	0.0 ...20.0 mA	1µA/digit

	AnalogChann:	M--
Output of 2.5V using the 10V output = 5000 digits:	AnalogVal:	+05000
switching back to the measuring channel by using the key:	<OFF>	
switching back to the previous programming value:	<ON>	

12. TROUBLESHOOTING

The data logger ALMEMO® 2590-9 can be configured and programmed in many different ways. It allows for a connection of many different sensors, additional measuring instruments, alarm signalisers and peripheral devices. Due to the large variety of options it is possible that, under certain conditions, it does not perform as the user would expect. In most cases this will not be related to a defective device but to operating errors such as wrong settings or an inadmissible wiring. The following tests should be performed to correct or to correctly identify the error.

Error: No display at all or faulty display, no key response.

Remedy: Check power supply, recharge battery, switch off and on again, reinitialise, if required (see 3.4).

Error: Incorrect measured values.

Remedy: Thoroughly check the entire programming of the channel (particularly base and zero point) (menu 'Sensor Programming' and 'Special Functions'.

Error: Varying meas. values, segment test or blockage during operation.

Remedy: Check cabling for inadmissible electrical connection, disconnect all suspicious sensors, connect hand-held sensors and operate them in air or connect dummies (short circuit AB at thermocouples, 100 ohms at Pt100 sensors) and check, then reconnect sensors successively and check.
If an error occurs with one sensor, check the wiring, isolate the sensor if necessary, prevent influences from disturbances by shielding or twisting.

Error: "CALErr" is displayed when the device is switched on.

Remedy: The calibration of a measuring range may have become misadjusted; the device must be recalibrated at the factory.

Error: Data transmission via interface does not function.

Remedy: Check interface module, connections and setting:
Are both devices set to the same baud rate and transmission mode (see 10.3)?
Is the correct COM interface addressed at the computer?
Is a printer in ONLINE mode?
Are the handshake lines DTR and DSR active?



A small interface tester with LEDs is very useful for checking the data flow and the handshake lines (during standby mode the data lines TXD and RXD are on a negative potential of approximately -9V and the diodes are illuminated green. The handshake lines DSR, DTR, RTS and CTS have a positive voltage of approximately +9V and the LEDs are illuminated red. During the data transmission the data lines must flash red).

Test the data transmission by using a terminal (AMR-Control, WIN-Control, DATA-Control, WINDOWS Terminal):

Select output channel interface U by using the command 'A1'.

Address the device with its device number 'Gxy' (see manual 6.2.1), if the computer is in XOFF state, enter <Strg Q> for XON, query the programming through 'P15' (see manual 6.2.3).

Only check the sending line by cycle input via command Z123456 and control in the display.

Test the receiving line with the key <PRINT> and by monitor control.

Error: Data transmission within the network does not function.

Remedy: Check that all devices are set to different addresses, address all devices individually via terminal and command 'Gxy', addressed device is OK when the feedback is at least 'y CR LF'. If data transmission is still not possible, disconnect networked devices, check all devices separately using the data cable of the computer (see above), check the wiring regarding short circuit or twisting.

Are all network distributors supplied with power?

Network and check the devices successively again (see above).

If the device is, after the above inspections, still not performing as specified in the operating instructions, it must be sent to the factory in Holzkirchen, Germany, including a short report and, possibly, control printouts. The software AMR-Control allows to print the monitor pages including the programming and also to save the terminal operation and to print it out.

ELECTROMAGNETIC COMPATIBILITY

The data logger ALMEMO® 2590-9 meets the essential electromagnetic compatibility (EMC) safety requirements specified in the relevant CE directive issued by the council for the alignment of legal regulations of the member states (89/336/EWG).

The following standards have been applied for the evaluation of the product:

EMC: IEC 61326:1997+A1:1998+A2:2000

IEC 61000-6-1:1997

IEC 61000-6-3:1996

IEC 61000-4-2: 1995+A1:1998+A2:2000 8kV IEC 61000-4-4: 1995+A1:2000 2kV

IEC 61000-4-3: 1995+A1:1998+A2:2000 3V/m

The following notes must be observed when operating the instrument:

1. If the standard sensor cables (1.5m) are extended it must be considered that the measuring lines are not guided together with power mains and that they are appropriately shielded to protect against any coupling of disturbance signals.
2. If the instrument is operated within strong electromagnetic fields an additional measuring error must be expected (<50µV at 3V/m and 1.5m thermocouple transducers). After the irradiation the device operates again within the specified technical data.

Technical Data (see also section 2.2 in ALMEMO® Manual)

Measuring inputs:	9 ALMEMO® sockets for ALMEMO® flat connectors
Meas. channels:	9 primary channels electr. isol., max. 27 add. chann. for double sensors and function channels
Analog/digital converter	delta-sigma 16bit, up to 50 measuring operat. per sec.
Sensor voltage supply:	battery pack: 7.2...9V, max. 100mA mains adapter: approx. 12V, max. 100mA
Outputs:	2 ALMEMO® sockets for all output modules
Equipment:	
Display:	graphics 128x128 dots, 16 lines, 21 characters 4mm
Operation:	6 keys (4 soft keys) and operating dial
Memory:	500 kB (100000 meas.val.) buffered with Lithium batt.
Time and date:	real time clock buffered with Lithium battery
Microprocessors:	HD 6303 Y, M16C62
Power supply:	ext. 7...13VDC not electr. isolated (center pin=minus)
Battery pack:	int. 6 NiCd R6 round cells 7.2...9V, 1.6Ah, fuse: 5A
Mains adapter:	ZB 2590-NA 230VAC to 12VDC, 800mA electr. isol.
Adapter cable electric. isolated:	ZB 2590-UK 10...30VDC to 12VDC, 1A
Current consumption without	active mode: approx. 31 mA
input and output modules:	with illumination: approx. 57 mA without display: approx. 25 mA sleep mode: approx. 0.2 mA
Housing:	204x109x44mm, ABS high impact strength(70°Cmax)
Operating conditions:	
Operating temperature:	0 ... +50°C (storage temperature: -20 ... +60°C)
Humidity of ambient air:	10 ... 90% rH (non-condensing)
Extent of the delivery:	Meas.instr. ALMEMO 2590-9, mains adapter 12V, 0.8A Operating Instructions ALMEMO 2590-9 ALMEMO® Manual with software AMR-Control

Product Overview

Order No.

Data Logger ALMEMO 2590-9

9 inputs, max. 36 channels, 2 outputs, cascable interface,
real time clock, 500kB memory (100000 meas.values), LCD graphics display,
6 keys, operat. dial, batt. pack, sleep mode, mains supply adapter and charger
Option: Slot for Smart Media Memory Card

MA 2590-9
OA 2590-SC

Smart Media Memory Card 8MB (up to 1,600,000 meas. values)
Supplementary battery pack NiCd 7.2V 1.600 mAh
DC Adapter Cable 10 to 30VDC, 12V/1A electr. isol.
ALMEMO® Recording Cable -1.25 to 2.00 V
ALMEMO® Data Cable V24 Interface, electr. isolated
ALMEMO® I/O Cable for Triggering and Limit Value Alarm

ZB 1904-SC8
ZB 2590-AP
ZB 2590-UK
ZA 1601-RK
ZA 1909-DK5
ZA 1000-EGK

Keyword Index

Keyword	Chapter	Page
A dditional channels	4.2	14
Alarm cable, configuration	11.2	63
Analog output, scaling, channel selection	11.3	64
Analog output, control via interface	11.3	64
Analog output, start and end of range	9.10.4	58
Atmospheric pressure	10.6	61
Atmospheric pressure compensation	6.3.4	28
Attenuation of meas. values	6.4.1	29
Attenuation, measured value	6.4.1	29
Averaging mode	6.4.2, 9.3	30, 51
Averaging	6.4	29
Averaging over time	6.4.5	32
Averaging over manual single measurements	6.4.3	30
Averaging over cyclic measuring point scans	6.4.4	31
Averaging, moving	6.4.1	29
B ar chart	6.4.7, 6.6	33, 36
Base value	9.6	52
Battery operation	3.1	12
Baud rate	10.3	61
C hanging the dimension	9.8	53
Channel selection, analog output	11.3	64
Configuration, user menus via interface	6.6.2	40
Configuration, user menus via keypad	6.6	36
Configuration, relay trigger cable	11.2	63
Connection of the transducers	4	14
Contacts		68
Continuous output/storage of all measuring points	6.2.5	25
Continuous measuring point scan	7.4	42
Contrast, display	10.5	61
Control symbols	5.3	17
Conv. rate	7.4	42
Correction values	9.7	53
Correction of measured values	6.3	26
Cyclic acquisition/storage of all measuring points	6.2.2	23
D ata acquisition	8.2	45
Data entry	5.5	18
Data format	10.3	61
Data storage	8	44
Data cable	11.1	62
Data buffering	3.5	13
Date	7.1	41
Decimal point setting	9.6	52

Keyword	Chapter	Page
Device address	10.2	60
Device designation	10.1	60
Device configuration	10	60
Display	5	16
Display of several measuring points	6.5	34
Display of measured values as line chart	6.2.4	24
Display options for measured values	6	21
Display, illumination	10.5	61
Display, contrast	10.5	61
Displaying a measuring point	6.1	22
E lectromagnetic compatibility	11	66
Element flags	9.10.8	59
End time and date, data recording	7.5	43
End time and date, memory output	8.5	47
Exponent	9.6	52
External voltage supply	3.3	13
F actor	9.6	52
Function range	1.1	6
Function printouts	6.6.1	39
Function keys	5.2	17
Function selection	5.4	18
H ysteresis	10.7	61
I llumination, display	10.5	61
Initial operation	2	11
Introduction	1	6
K eypad	5	16
L anguage setting	10.4	61
Limit value responses	9.10.3	57
Limit values	9.5	52
Line chart, range start and end	9.10.4	58
Line chart	6.2.4	24
Locking, sensor programming	9.4	51
Locking, menus	5.6	19
Locking, keypad	5.6	19
M ains operation	3.2	12
Maximum values with time and date	6.1.2	22
Meas. menus	6.1	21
Measurement time	6.4.6	32
Measuring point selection	6.1.1	22
Measuring inputs	4.2	14
Measuring	6	21
Measuring point scans and output	6.2	23

Keyword	Chapter	Page
Measuring point designation	9.2	51
Measuring cycle, storage activation	7.3	42
Memory output and clearing	6.2.6	25
Memory output	8.5	47
Memory display	8.4	46
Memory space	6.2.6	25
Menu configuration	6.6	36
Menu selection	5.1	16
Menu, 'Memory'	8.2	45
Menu, 'Sensor Programming'	9	50
Menu, 'Device Configuration'	10	60
Menu, 'Line Chart'	6.2.4	24
Menu, 'Meas. Correction'	6.3	26
Menu, 'Meas. Point List'	6.5.2	35
Menu, 'Averaging'	6.4	29
Menu, 'Special Functions'	9.10	56
Menu, 'Standard Display'	6	21
Menu, 'Flow'	6.4.7	33
Menu, 'Times and Cycles'	7	41
Menu, 'Monitoring'	6.1.2	22
Menu, 'Multi Channel Display'	6.5.1	34
Menu, 'Data Logger'	6	21
Minimum sensor supply voltage	9.10.2	56
Multiplexer	9.10.7	59
Networking	10.2	60
Numbering of measurements	8.3	46
Operating controls		2
Operating parameters	10.8	62
Option Smart Media Card	8.1	44
Output relays, manual triggering	11.2	63
Output of menu functions	6.1.3	23
Output function	9.10.5	58
Output modules	11	62
Output format	6.2.3, 7.2	24, 41
Peak value memory with time and date	6.1.2	22
Power supply	3	12
Print cycle, timer	6.2.3	24
Print cycle, storage activation	7.2	41
Print cycle factor	9.10.1	56
Product overview		67
Reference channel 1 / 2	9.10.6/7	59
Reinitialisation	3.4	13
Relay trigger cable, configuration	11.2	63

Keyword	Chapter	Page
Relay triggering	11.2	63
Relay allocation	9.10.3	57
Reset	3.4	13
S caling, analog output, line chart	11.3	64
Scaling, measured value	9.6	52
Selecting the measuring range	9.9	53
Selecting the measuring point	6.1.1	22
Selecting the input channel	9.1	50
Sensor programming	9	50
Sensor supply voltage	9.10.2	56
Setpoint entry	6.3.2	27
Setting the measured value to zero	6.3.1	26
Single output/storage of all measuring points	6.2.1	23
Sleep mode	8.6	48
Slope (gain) correction	9.7	53
Smart Media Card	8.1	44
Special functions	9.10	56
Start time and date, data recording	7.5	43
Start time and date, memory output	8.5	47
Storage activation, print cycle	7.2	41
Storage activation, measuring cycle	7.3	42
Storing all measuring points, manually, once only	6.2.1	23
Storing all measuring points, cyclic	6.2.2	23
Supply voltage control	3.1	12
Switch on/off	3.4	13
T able of contents		3
Technical data		67
Temperature compensation	6.3.3	28
Time interval, memory output	8.5	47
Time and date	7.1	41
Time and date, maximum values	6.1.2	22
Times and cycles	7	41
Transducer	4.1	14
Troubleshooting	12	65
U ser menus	6.6	36
V olume flow measurement	6.4.7	33
Z ero point adjustment	6.3.1	26
Zero point correction	9.7	53

